



"Service the Service Industry Relies Upon"

Quick Reference Guide

Corporate Headquarters/Distribution Center

One International Lane
Rhineland, WI 54501
Phone: 715-369-5995

East Coast Distribution Center

Chambersburg, PA

West Coast Distribution Center

Las Vegas, NV

Texas Distribution Center

Marshall, TX

Table of Contents

Index	Page: 1-2	HP Monochrome Printer Parts Continued	Page: 6	HP Monochrome MFP Printer Parts Continued	Page: 9-13
HP Monochrome Printer Parts	Pages: 3-13				
HP LaserJet 4+	3	HP LaserJet 8000	6	HP LaserJet 3392MFP	9
HP LaserJet 4V	3	HP LaserJet 8100/8150	6	HP LaserJet 4100MFP	9
HP LaserJet 5	3	HP LaserJet 9000	6	HP LaserJet 4101MFP	10
HP LaserJet 5L	3	HP LaserJet 9040/9050	6	HP LaserJet 4345MFP	10
HP LaserJet 5P	3	HP LaserJet M401	6	HP LaserJet 8550MFP	10
HP LaserJet 5Si	3	HP LaserJet M601	6	HP LaserJet 9000MFP	10
HP LaserJet 6L	3	HP LaserJet M602/603	6	HP LaserJet 9040MFP	10
HP LaserJet 6P	3	HP LaserJet M712	6	HP LaserJet 9050MFP	10
HP LaserJet 1005	3	HP LaserJet P1005/P1006	7	HP LaserJet 9055MFP	11
HP LaserJet 1010	3	HP LaserJet P1505	7	HP LaserJet 9065MFP	11
HP LaserJet 1012/1015	4	HP LaserJet P1606	7	HP LaserJet 9085MFP	11
HP LaserJet 1020	4	HP LaserJet P2015	7	HP LaserJet M1005	11
HP LaserJet 1022	4	HP LaserJet P2035	7	HP LaserJet M1120	11
HP LaserJet 1100	4	HP LaserJet P2055	7	HP LaserJet M1132	11
HP LaserJet 1150	4	HP LaserJet P3005	7	HP LaserJet M1212/M1217*	11
HP LaserJet 1160	4	HP LaserJet P3015	7	HP LaserJet M1319	11
HP LaserJet 1200	4	HP LaserJet P4014	7	HP LaserJet M1522	12
HP LaserJet 1300	4	HP LaserJet P4015/4515	7	HP LaserJet M1536	12
HP LaserJet 1320	4	HP Monochrome MFP Printer Parts	8-13	HP LaserJet M2727	12
HP LaserJet 2100	4	HP LaserJet 3015MFP	8	HP LaserJet M3027	12
HP LaserJet 2200	5	HP LaserJet 3020MFP	8	HP LaserJet M3035	12
HP LaserJet 2300	5	HP LaserJet 3030MFP	8	HP LaserJet M425	12
HP LaserJet 2410/20/30	5	HP LaserJet 3050MFP	8	HP LaserJet M4345	12
HP LaserJet 4000/4050	5	HP LaserJet 3052MFP	8	HP LaserJet M4555	12
HP LaserJet 4100	5	HP LaserJet 3055MFP	8	HP LaserJet M5025	13
HP LaserJet 4200	5	HP LaserJet 3100MFP	8	HP LaserJet M5035	13
HP LaserJet 4240	5	HP LaserJet 3150MFP	8	HP LaserJet M521	13
HP LaserJet 4250/4350	5	HP LaserJet 3200MFP	9	HP LaserJet M525	13
HP LaserJet 4300	5	HP LaserJet 3310MFP	9	HP LaserJet M525C	13
HP LaserJet 5000	5	HP LaserJet 3320MFP	9	HP LaserJet M725	13
HP LaserJet 5100	6	HP LaserJet 3330MFP	9	HP LaserJet M9040/9050	13
HP LaserJet 5200	6	HP LaserJet 3380MFP	9		
		HP LaserJet 3390MFP	9		

Table of Contents														
HP CLJ Printer			Page:	14-17	HP CLJ Printer Parts			Continued	Page:	17	Lexmark Printer Parts		Page:	25-27
HP CLJ 1500				14	HP CP6015				17	Lexmark S1250				25
HP CLJ 1600				14	HP M251				17	Lexmark S1250				25
HP CLJ 2500				14	HP M351/M451				17	Lexmark S1255				25
HP CLJ 2550				14	HP M551				17	Lexmark S1620				25
HP CLJ 2600				14	HP CLJ MFP Printer Parts				18-20	Lexmark S1625				25
HP CLJ 2605				14	HP CLJ MFP 1015				18	Lexmark S1650				25
HP CLJ 3000				14	HP CLJ MFP 1017				18	Lexmark S1855				25
HP CLJ 3500				14	HP CLJ MFP 2820				18	Lexmark S2420				25
HP CLJ 3550				14	HP CLJ MFP 2830				18	Lexmark S2450				25
HP CLJ 3600				14	HP CLJ MFP 2840				18	Lexmark S2455				25
HP CLJ 3700				15	HP CLJ MFP 4730				18	Lexmark Se3455				25
HP CLJ 3800				15	HP CLJ MFP 9500				18	Lexmark T420				26
HP CLJ 4500JPG<				15	HP CM1312				18	Lexmark T430				26
HP CLJ 4500JPH-JPZ				15	HP CM1415				19	Lexmark T520				26
HP CLJ 4550				15	HP CM2320				19	Lexmark T522				26
HP CLJ 4600				15	HP CM3530				19	Lexmark T610				26
HP CLJ 4650				15	HP CM4540				19	Lexmark T612				26
HP CLJ 4700				15	HP CM4730				19	Lexmark T614				26
HP CLJ 5500				15	HP CM6030/6040				19	Lexmark T616				26
HP CLJ 5550				16	HP M175				19	Lexmark T620				26
HP CLJ 5800				16	HP M272				19	Lexmark T622				26
HP CLJ 8550				16	HP M276				20	Lexmark T630				27
HP CLJ 9500				16	HP M375				20	Lexmark T632				27
HP CP1215				16	HP M475				20	Lexmark T640				27
HP CP1518				16	HP M570				20	Lexmark T642				27
HP CP2025/CP2035				16	HP M575				20	Lexmark T644				27
HP CP3505				16	HP M575C				20	Lexmark T650				27
HP CP3525				16	HP M775				20	Lexmark T652				27
HP CP4005				17	HP Firmware Versions and Part #'s				21	Lexmark T654				27
HP CP4025				17	HP Jet Direct Cards				22	Lexmark Error Codes				28-29
HP CP4525				17	HP LaserJet Entering Service Mode				23-24	LPI Contact Information				30
HP CP5225				17						Website Key Points				30

HP Monochrome Printer Parts

Description	4+	4V	5	5L	5P	5Si	6L	6P	1005	1010
Control Panel	RG5-1077	RG5-1539	RG5-2238	RG5-2028		RG5-2433	RG5-2028		RG0-1167	
DC Controller	RG5-0966	RG5-1559	RG5-0966	RG5-2023	RG5-1798	RG5-1844	RG5-3506	RG5-2826		
Delivery Assembly	RG5-0886		RG5-2189	RG5-5482		RG5-2410	RG5-5482	RG5-0681	RG0-1010	
Deliver Roller	RF5-1076/77	RG5-0198		RF5-1521	RG5-0683	RB1-6686/87	RF5-2367	RG5-0683		
Drive (Main)	RG5-0876	RG5-1398	RG5-0876		RG5-1713	RG5-1847		RG5-2778	RM0-1001	
(Delivery)										
(Fuser)										
Engine Controller				RG5-2023	RG5-1798		RG5-3506	RG5-2826	RG0-1166	RM1-0806
Formatter (Simplex)	C2038-69001	C3143-69001	C3919-69001	C3942-69002	C3151-69001	C3168-69006	C3991-69001	C3981-69001	Q2678-67901	
(Network)										
(Duplex)										
Fuser	RG5-0879	RG5-1557	RG5-0879	RG5-3497	RG5-1700	RG5-4447	RG5-3459	RG5-4110	RG9-1493	RM1-0660
Laser Scanner	RG5-0903	RG5-2041	RG5-0903	RG5-2000	RG5-1780	RG5-1895	RG5-3497	RG5-2848	RG9-1486	RM1-0171
Main Motor	RH7-1301	RH7-1199	RH7-1301	RH7-1320	RG5-1799	RH7-1260	RH7-1320	RG5-2786	RH7-1473	
Maintenance Kit	C2037-69010	C3141-69010	C3916-69001	C3941-69007	H3973-69001	C3971-69002	C3941-69007	H3966-69001		
Power Supply-HV	RG5-0969	RG5-2044	RG5-0969		RG5-0969	RG5-1888	RG5-3506			
Power Supply-LV	RG5-2499	RH3-2150	RG5-2499			RG5-3676				RM1-0807
Registration						RG5-1833				
Service Manual	C3916-90984	C3141-90929	C3916-90984	C3990-90991	C3980-91078	C4077-99016	C3990-90991	C3980-91078	Q2676-90915	Q5911-90945
Toner	92298A	C3900A	92298A	C3906A	C3903A	C3909A	C3906A	C3903A	C7115A/X	Q2612A
Transfer Roller	RF5-0349	RG5-1410	RF5-0349	RF5-1534	RF5-0596	RF5-1412	RF5-1534	RF5-0596	RG9-1483	RM1-0658
Tray 1 P/U Asm	RG5-0877	RG5-2248	RG5-2195	RB2-1634	RG9-1083	RG5-1880	RB2-1634	RG5-2790	RG0-1003	RM1-0641
T1 P/U Roller	RB1-2127	RB1-1411	RB1-2205	RG5-3486	RB1-2205	RB1-6730	RG5-3486	RB1-2205	RF0-0303	RL1-0266
Tray 1 Sep Pad	RF5-0343	RF5-0302	RF5-0343	RY7-5077K	RF5-0343	RF5-1455	RY7-5077K	RF5-0343	RF0-1014	RM1-0648
Tray 2 P/U Asm	RG5-0877	RG5-1391	RG5-2195		RG5-2796	RG5-1852		RG5-2796		
T2 P/U Roller	RB1-3477	RB1-1386	RB1-7911		RB1-6332	RF5-1835		RB1-6332		
Tray 2 Sep Pad										
T2 Feed/Sep Roll										
Tray 3 P/U Asm	RG5-1099					RG5-1852				
T3 P/U Roller	RB1-2650	C3760-60506				RF5-1835				
Tray 3 Sep Pad						RF5-1834x2				
T3 Feed/Sep Roller										
High Cap P/U Roller										
High Cap Feed/Sep										

HP Monochrome Printer Parts

Description	1012/1015	1020	1022	1100	1150	1160	1200	1300	1320	2100
Control Panel					RM1-0549	RM1-1311	RG0-1024	RM1-0549	RM1-1312	
DC Controller										
Delivery Assembly				RG5-4593	RM1-0556		RG0-1010	RM1-0556		RF5-2604
Deliver Roller				RF5-2830		RL1-0527			RL1-0527	
Drive (Main)				RG5-4586	RM1-0678	RM1-1299	RG0-1001	RM1-0527	RM1-1299	RG5-4131
(Delivery)						RM1-1305				
(Fuser)										
Engine Controller	RM1-0806	RM1-2314	RM1-2309	RG5-4605	RM1-0566	RM1-1242	RG0-1012	RM1-0564	RM1-1242	RG5-4125
Formatter (Simplex)		CB409-60001	CB406-60001	C4146-60001	Q2455-60001	CB358-67901	C7857-60001	Q1890-69001	CB355-67901	C4132-60001
(Network)									CB356-67901	
(Duplex)										
Fuser	RM1-0660	RM1-2086	RM1-2049	RG5-4589	RM1-0715	RM1-1289	RG9-1493	RM1-0715	RM1-1289	RG5-4132
Laser Scanner	RM1-0171	RM1-2084	RM1-2033	RG5-4570	RM1-0524	RM1-1470	RG9-1486	RM1-0524	RM1-1470	RG5-4172
Main Motor				RH7-1404	RK2-0063	RK2-0419	RH7-1473	RK2-0063	RK2-0419	RH7-1381
Maintenance Kit				H3965-60001	1150/1300K		1000/1200/3300K	1150/1300K		H3974-60001
Power Supply-HV										
Power Supply-LV	RM1-0807	RM1-2315	RM1-2310							
Registration						RM1-1281			RM1-1281	RG5-4129
Service Manual	Q5911-90945	Q5911-90945	Q5912-90901	C4224-90962	Q1334-90928	Q5927-90965	C7044-90906	Q1334-90928	Q5927-90965	C4170-90959
Toner	Q2612A	Q2612A	Q2612A	C4092A	Q2624A	Q5949A/X	C7115A/X	Q2613A/X	Q5949A/X	C4096A
Transfer Roller	RM1-0658	RM1-2093	RM1-2062	RG5-4657	RM1-0550	RM1-1471	RG9-1483	RM1-0550	RM1-1471	RG5-4164
Tray 1 P/U Asm	RM1-0641	RM1-2091	RM1-2043		RM1-0531		RG0-1003	RM1-0531		RG5-4128
T1 P/U Roller	RL1-0266	RL1-0266	RL1-0266	RB2-4026	RL1-0303		RL1-0303	RL1-0303		RB2-2900
Tray 1 Sep Pad	RM1-0648	RM1-0648	RM1-2048	RF52886	RF0-1014		RF0-1014	RF0-1014		RB2-6348
Tray 2 P/U Asm										RG5-4127
T2 P/U Roller						RL1-0540			RL1-0540	RB2-2891
Tray 2 Sep Pad						RM1-1298			RM1-1298	RB2-6349
T2 Feed/Sep Roll										
Tray 3 P/U Asm										
T3 P/U Roller										RB2-2891
Tray 3 Sep Pad										RB2-6474
T3 Feed/Sep Roller										
High Cap P/U Roller										
High Cap Feed/Sep										

HP Monochrome Printer Parts

Description	2200	2300	2410/20/30	4000/4050	4100	4200	4240	4250/4350	4300	5000
Control Panel		RH6-0226	RM1-1519	RG5-5372	RG5-5372	RM1-1195	RM1-1195	RM1-1195	RM1-1195	RG5-3604
DC Controller	RG5-5566	RG1-4307	RM1-1516			RG1-4236	RM1-1108	RM1-1108	RG1-4237	C4110-67906
Delivery Assembly		RM1-0371		RG9-1326	RG5-5094	RM1-0026	RM1-0026	RM1-0026	RM1-0026	RG5-3542
Deliver Roller	C7058-67905	C7058-67905	RL1-0580							RB2-1985
Drive (Main)	RG5-5562	RM1-0334	RM1-1512	RG5-2653	RG5-5087	RM1-0001	RM1-1066	RM1-1066	RM1-0001	RG5-3543
(Delivery)				RG5-3721	RG5-5095					
(Fuser)		RM1-0354	RM1-1535			RM1-0043	RM1-0043	RM1-0043	RM1-0043	
Engine Controller	RG5-5566		RM1-1516	RG5-3693	RG5-5359					
Formatter (Simplex)	C7066-60001	Q1395-60002	Q6508-61005	*See bottom	C4169-69001	C9652-69001	Q6506-69010	Q6506-69010	C9651-69001	C3974-69001
(Network)			Q6507-61004				Q6505-69010	Q6505-69010		
(Duplex)	C4209-69001									
Fuser	RG5-5559	RM1-0354	RM1-1535	RG5-2661	RG5-5063	RM1-0013	RM1-1082	RM1-1082	RM1-0101	RG5-5455
Laser Scanner	RG5-5591	RM1-0313	RM1-1521	RG5-2641	RG5-5100	RM1-0045	RM1-1067	RM1-1067	RM1-0113	RG5-4811
Main Motor	RH7-1458	RH7-1588	RK2-0523	RH7-1331	RH7-1504	RH7-1570	RK2-0273	RK2-0273	RH7-1570	RH7-1357
Maintenance Kit	H3978-60001	U6180-60001		C4118-67911	C8057AK	Q2429A	Q5421A	Q5421A	Q2436AK	C4110-69006
Power Supply-HV			RM1-1505							
Power Supply-LV	RG5-5563	RG1-4306				RM1-0019	RM1-1070	RM1-1070	RM1-0107	RH3-2195
Registration	RG5-5556	RM1-0347	RM1-1502	RG5-2652	RG5-5085	RM1-1098	RM1-1098	RM1-1098	RM1-1098	RG5-3524
Service Manual	C7058-90980	Q2472-90911	Q5956-90940	C4118-91026	C8049-90925	Q5400-90932	Q5400-90632	Q5400-90932	Q5400-90932	C4110-91041
Toner	C4096A	Q2610A	Q6511A/X	C4127A/X	C8061A/X	Q1338A	Q5942A/X	Q5952A/X	Q1339A	C4129X
Transfer Roller	RG5-5581	RM1-0343	RM1-1508	RG5-4283	RG5-5295	RM1-0699	RM1-1110	RM1-1110	RM1-0699	RG5-3579
Tray 1 P/U Asm	RG5-4128	RM1-0346		RG5-2655	RG5-5084	RM1-0004	RM1-1097	RM1-1097	RM1-0004	RG5-3519
T1 P/U Roller	RB2-2900	RC1-0945	RL1-0568	RG5-3718	RG5-3718	RL1-0019	RL1-0019	RL1-0019	RL1-0019	RB2-1820
Tray 1 Sep Pad	RF5-3272	RC1-0939	RC1-0939	RG5-5281	RF5-3086	RL1-0007	RL1-0007	RL1-0007	RL1-0007	RF5-3439
Tray 2 P/U Asm	C7058-67907	RM1-0332	RM1-1481	RG5-2683	RG5-5277	RM1-0034	RM1-0034	RM1-0034	RM1-0034	RF5-3521
T2 P/U Roller	RB2-6304	RB2-6304	RL1-0542	RG5-2672	RB1-8957x4	RM1-0036	RM1-0036	RM1-0036	RM1-0036	RB2-1821
Tray 2 Sep Pad	RB2-6349	RC1-0954	RM1-1298	RB1-8957x4						
T2 Feed/Sep Roll				RF5-1885x2	RF5-3114x2	RM1-0037x2	RM1-0037x2	RM1-0037x2	RM1-0037x2	
Tray 3 P/U Asm				RG5-2684	RG5-5293					RG5-4183
T3 P/U Roller	RB2-2891	RB2-6304	RL1-0542	RB1-8957x4	RB1-8957x4	RM1-0036	RM1-0036	RM1-0036	RM1-0036	RB1-8865x4
Tray 3 Sep Pad	RB2-6474	RB2-9960								
T3 Feed/Sep Roller			Call Tech	RF5-1885x2	RF5-3114x2	RM1-0037x2	RM1-0037x2	RM1-0037x2		RF5-2634x2
High Cap P/U Roller						RM1-0036	RM1-0036	RM1-0036	RM1-0036	
High Cap Feed/Sep						RM1-0037x2	RM1-0037x2	RM1-0037x2	RM1-0037x2	

*4000/4050 same parts but different formatters; 4000=C4118-69008, 4050=C4251-69001

HP Monochrome Printer Parts

Description	5100	5200	8000	8100/8150	9000	9040/9050	M401	M601	M602/603	M712
Control Panel	RG5-3604	RK2-1097	RG5-4384	RG5-4384	RG5-5703	RG5-5703	*Call Tech*	RM1-8290	RM1-8289	RM1-8940
DC Controller	RG5-7057	RM1-4098	RG5-1844	RG5-4375	RG5-5778	RG5-7780	RM1-9164	RM1-8293	RM1-8293	RM1-8934
Delivery Assembly	RG5-3542	RM1-2490	RG5-2410	RG5-2410	RG5-5643	RG5-5643		RM1-8414	RM1-8414	
Deliver Roller	RB2-1985									
Drive (Main)	RG5-7079		RG5-1847	RG5-4365				RM1-8489	RM1-8489	RM2-0184
(Delivery)					RG5-5659	RG5-7789				
(Fuser)						RG5-7789		M600-GK ?	M600-GK ?	RM1-2963
Engine Controller							RM1-9164			
Formatter (Simplex)	Q1860-67901	Q6497-69002	C4186-69001	*See bottom	C8519-69001	Q3721-69001	CF148-60001			
(Network)		Q6498-69001				Q3722-69002	CF149-60001	CE988-67906	CE988-67906	CF235-67902
(Duplex)							CF150-60001 & N			
Fuser	RG5-7060	RM1-2522	RG5-4447	RG5-6532	RG5-5750	RG5-5750	RM1-8808	RM1-8395	RM1-8395	CF235-67921
Laser Scanner	RG5-7041	RM1-2555	RG5-1895	RG5-4344	RG5-5826	RG5-5826	RM1-9135	RM1-8406	RM1-8406	RM1-8679
Main Motor	RH7-1428	RM1-2516	RH7-1260	RH7-5219	RH7-1656	RH7-1656	RM1-9042			
Maintenance Kit	Q1860-67908		C3971-67904	C3914-69001	C9152-69002	C9152-69002		CF064-67901	CF064-67901	CF235-67907
Power Supply-HV		RM1-2957	RG5-1888	RG5-4306	RG5-5728	RG5-5728				RM2-7538
Power Supply-LV	RH3-2248	RM1-2926	RG5-3676	RG5-4357	RG5-5730	RG5-5730		RM1-8392	RM1-8392	RM1-8744
Registration	RG5-4916	RM1-2506	RG5-1833	RG5-4303	RG5-5663	RG5-5663	RM1-8806	RM1-8413	RM1-8413	RM1-8671
Service Manual	Q1860-90918	Q7543-90934	C4085-91087	C4214-99021	Q3721-90963	Q3721-90963	CF270-90977			CF235-90962
Toner	C4129X	Q7516A	C3909A	C4182X	C8543X	C8543X	CF280A/X	CE390A/X	CE390A/X	CF214A/X
Transfer Roller	RG9-1542	RM1-2485	RF5-1412	RF9-1394	RF5-3319	RF5-3319	RM1-9175	RM1-8491	RM1-8491	CF235-67910
Tray 1 P/U Asm	RG5-3519		RG5-1880	RG5-4330	RG5-5809	RG5-5809		RM1-8425	RM1-8425	
T1 P/U Roller	RB2-1820	RL1-0915	RB1-6730	RB1-9526	RF5-3403	RF5-3403	RL1-3307	CB988-67905 Kit	CB988-67905 Kit	CF235-67906 Kit
Tray 1 Sep Pad	RF5-4119	RM1-2462	RF5-1455	RF5-2703	RF5-3403	RF5-3403	RL1-2115	Included in T1 Kit	Included in T1 Kit	Included in T1 Kit
Tray 2 P/U Asm	RG5-3521	RM1-2530	RG5-1852	RG5-4334	RG5-5681	RG5-5681				ERM2-0182
T2 P/U Roller	RB2-1821	RM1-0731	RF5-1835	RF5-2708	RF5-3340	RF5-3340	RM1-9168	RM1-0036	RM1-0036	CF235-67909 Kit
Tray 2 Sep Pad	RF5-4120	RM1-2546					RM1-7365			Included in T2/3 Kit
T2 Feed/Sep Roll		RM1-0037x2	RF5-1834x2	RF5-1834x2	RF5-3338x2	RF5-3338x2		RM1-0037x2	RM1-0037x2	
Tray 3 P/U Asm	RG5-7194	RM1-2896	RG5-1852	RG5-4334	RG5-5681	RG5-5681				RM2-0183
T3 P/U Roller	RB1-8865x4	RM1-0036	RF5-1835	RF5-2708	RF5-3340	RF5-3340	RM1-9168	RM1-0036	RM1-0036	Included in T2/3 Kit
Tray 3 Sep Pad							RM1-6303			Included in T2/3 Kit
T3 Feed/Sep Roller	RF5-2634x2	RM1-0037x2	RF5-1834x2	RF5-1834x2	RF5-3338x2	RF5-3338x2		RM1-0037x2	RM1-0037x2	
High Cap P/U Roller			RF5-1835	RF5-2708	RF5-3338	RF5-3338		RM1-0036	RM1-0036	CC522-67909
High Cap Feed/Sep			RF5-1834x2	RF5-1834x2	RF5-3338x2	RF5-3338x2		RM1-0037x2	RM1-0037x2	

**8100/8150 same parts but different formatters; 8100=C4107-69008, 8150=C4265-69001*

HP Monochrome Printer Parts

Description	P1005/P1006	P1505	P1606	P2015	P2035	P2055	P3005	P3015	P4014	P4015/4515
Control Panel		RM1-4195			RM1-6435	RM1-6429	RM1-3725	RM1-6519 S RM1-6518 D	RM1-5060	RM1-5059
DC Controller							RM1-3730		RM1-4582	
Delivery Assembly					RM1-6647		RM1-3749		RM1-4529	RM1-4529
Deliver Roller				RL1-0527			RM1-3749	RM1-6311		
Drive (Main)				RM1-4253			RM1-3712			
(Delivery)									RM1-4526	RM1-4526
(Fuser)							RM1-3740		P4015-GK	P4015-GK
Engine Controller	RM1-4601	RM1-4627	RM1-7615	RM1-4273	RM1-6392	RM1-6392	RM1-3730	RM1-6281		
Formatter (Simplex)	RM1-4607/08	RM1-4216	RM1-7266	Q7804-60001	CC525-60001		Q7847-61006	CE474-69001	CB437-69001	CB437-69001
(Network)				Q7805-60002	CC525-60001	CC528-69002	Q7848-61006	CE175-36001	CB438-69001	CB438-69001
(Duplex)			RM1-7623			CC527-69002				
Fuser	RM1-4007	RM1-4228	RM1-7546	RM1-4247	RM1-6405	RM1-6405	RM1-3740	RM1-62740	RM1-4554	RM1-4554
Laser Scanner	RM1-4030	RM1-4184		RM1-4262	RM1-6424	RM1-6424	RM1-1521	RM1-6322	RM1-5465	RM1-5465
Main Motor	RM1-7544	RM1-4196	RM1-2544	RK2-1567	RM1-6378	RM1-6378	RK2-1488		RL1-1657	RL1-1657
Maintenance Kit				P2015MK					CB388A	CB388A
Power Supply-HV							RM1-3758	RM1-6300 S		
Power Supply-LV									RM1-4549	RM1-4549
Registration				RM1-4244	RM1-6419	RM1-6419	RM1-3715	RM1-6272	RM1-5460	RM1-5460
Service Manual				CB366-90905			Q7812-90910	CE544-90909	CB506-90950	CB506-90950
Toner	CB435A	CB436A	CE278A	Q7553A	CE505A/X	CE505A/X	Q7551A	CE255A	CC364A	CC364A
Transfer Roller	RM1-4023	RM1-4234	RM1-4023	RM1-4279	RM1-6450	RM1-6450	RM1-1508	RM1-6321	CB506-67903	CB506-67903
Tray 1 P/U Asm	RM1-4001	RM1-4224					RM1-3716		RM1-4563	RM1-4563
T1 P/U Roller	RL1-1442	RL1-1497		RL1-1525	RM1-6394	RM1-6394	RL1-0568	RL1-2412	RL1-1641	RL1-1641
Tray 1 Sep Pad	RM1-4006	RM1-4227		RL1-1524			RC1-0939	RC2-8575	RL1-1654	RL1-1654
Tray 2 P/U Asm							RM1-3762	RM1-6299 S RM1-6268 D		
T2 P/U Roller			RL1-1497	RL1-0540	RM1-6414	RM1-6414	RL1-1370	RM1-6313	RM1-0036	RM1-0036
Tray 2 Sep Pad			RM1-4227	RM1-1298	RM1-6397	RM1-6397	RM1-3738	RM1-6303		
T2 Feed/Sep Roll									RM1-0037x2	RM1-0037x2
Tray 3 P/U Asm										
T3 P/U Roller				RL1-0540			RL1-1370	RM1-6313	RM1-0036	RM1-0036
Tray 3 Sep Pad				RM1-1298				RM1-6303		
T3 Feed/Sep Roller									RM1-0037x2	RM1-0037x2
High Cap P/U Roller									RM1-0036	RM1-0036
High Cap Feed/Sep									RM1-0037x2	RM1-0037x2

HP Monochrome MFP Printer Parts

Description	3015MFP	3020MFP	3030MFP	3050MFP	3052MFP	3055MFP	3100MFP	3150MFP
Control Panel	RK2-0232	Q2665-60101	Q2666-60101	RK2-1209	Q6502-60101	Q6503-60101	RG5-4241	RG5-4769
DC Controller	RM1-0907	RM1-0907	RM1-0907					
Delivery Assembly							RG5-5482	RG5-5482
Delivery Roller							RF5-2367	RF5-2367
Drive (Main)								
(Delivery)								
(Fuser)								
Engine Controller				RM1-3404	RM1-3404	RM1-3404	RG5-4690	RG5-4690
Formatter (Base)	Q2668-60001	C2688-60002	Q2664-60001	Q7844-60002			C3949-67901	C3949-69002
(Network)					Q7528-60001	Q7529-60002		
Fuser	RM1-0865	RM1-0865	RM1-0865	RM1-3044	RM1-3044	RM1-3044	RG5-4678	RG5-4678
Laser Scanner	RM1-0171	RM1-0171	RM1-0171	RM1-2033	RM1-2033	RM1-2033	RG5-3497	RG5-3497
LIU	Q2663-60011		Q2663-60011	Q2663-60011		Q2663-60011	C3948-69001	C3948-69001
Main Motor	RK2-0107	RK2-0107	RK2-0107	RK2-0777	RK2-0777	RK2-0777	RH7-1320	RH7-1320
Maintenance Kit								
Power Supply High								
Power Supply Low	RM1-0903	RM1-0903	RM1-0903	RM1-3402	RM1-3402	RM1-3402		
Registration								
Service Manual	Q2665-90935	Q2665-90935	Q2665-90935				C3948-90956	C4256-90956
Toner	Q2612A	Q2612A	Q2612A	Q2612A	Q2612A	Q2612A	C3906A	C3906A
Transfer Roller	RM1-0658	RM1-0658	RM1-0658	RM1-2062	RM1-2062	RM1-2062	RF5-1534	RF5-1534
Tray 1 P/U Assembly	RM1-0864	RM1-0864	RM1-0864	RM1-3043	RM1-3043	RM1-3043	RG5-3484	RG5-3484
Tray 1 P/U Roller	RL1-0266	RL1-0266	RL1-0266	RL1-0266	RL1-0266	RL1-0266	RG5-3486	RG5-3486
Tray 1 Sep Pad or Roller	RM1-0648	RM1-0648	RM1-0648	RM1-2048	RM1-2048	RM1-2048	RY7-5077K	RY7-5077K
Tray 2 P/U Assembly								
Tray 2 P/U Roller								
Tray 2 Sep Pad								
Tray 2 Feed/Sep Roller								
Tray 3 P/U Assembly								
Tray 3 P/U Roller								
Tray 3 Sep Pad								
Tray 3 Feed/Sep Roller								
High Capacity P/U Roller								
High Capacity Feed/Sep								
ADF Parts								
ADF P/U Roller	RM1-0885	C7309-60091	C7309-60091	RM1-0885	5851-2559	5851-2559	RG5-4772	RG5-4772
ADF Sep Roller								
ADF Sep Pad	RM1-0890	C7309-60076	C7309-60076	RM1-0890	Q2665-60125	Q2665-60125	RY7-5055K	RY7-5055K
ADF Input Tray	RM1-0893	Q2665-60109	Q2665-60109	RM1-3419	Q3948-60214	Q3948-60214		
ADF Assembly		Q2665-60117	Q2665-60117		Q6502-60117	Q6502-60117		
Flatbed Scanner		Q2665-60117	Q2665-60117		Q6502-60116	Q6502-60116		

HP Monochrome MFP Printer Parts

Description	3200MFP	3310MFP	3320MFP	3330MFP	3380MFP	3390MFP	3392MFP	4100MFP
Control Panel	RG5-5406	C9709-60102	C9124-60108	C9126-60102	Q2660-60101	Q6500-60104	Q6500-60104	RG5-6563
DC Controller								
Delivery Assembly	RG5-4593	RG0-1010	RG0-1010	RG0-1010	RM1-0556			RG5-5094
Delivery Roller						RL1-0527	RL1-0527	
Drive (Main)	RG5-4586	RG0-1001	RG0-1001	RG0-1001	RM1-0835	RM1-1299	RM1-1299	RG5-5087
(Delivery)								RG5-5095
(Fuser)								
Engine Controller	RG5-5395	RG0-1117	RG0-1117	RG0-1117	RM1-0833	RM1-2566	RM1-2566	RG5-5359
Formatter (Base)	C4261-69001	C9158-60002	C9158-60002	C8542-60001	Q2658-67901			C7844-67901
(Network)						Q6445-60001	Q6445-60001	
Fuser	RG5-4589	RG9-1493	RG9-1493	RG9-1493	RM1-2075	RM1-1289	RM1-1289	RG5-5063
Laser Scanner	RG5-5421	RG9-1486	RG9-1486	RG9-1486	RM1-0524	RM1-1470	RM1-1470	RG5-5100
LIU	C7052-60004			C9138-60001	C9138-60001	Q3977-60001	Q3977-60001	Q1314-69003
Main Motor	RH7-1404	RH7-1473	RH7-1473	RH7-1473	RK2-0062	RK2-0418	RK2-0418	RH7-1504
Maintenance Kit								C8057AK
Power Supply High								
Power Supply Low								
Registration						RM1-1281	RM1-1281	RG5-5085
Service Manual	C7052-90998	C9124-90948	C9124-90948	C9124-90948	Q2660-90935	Q6445-60001	Q6445-60001	C9148-90909
Toner	C4092A	C7115A/X	C7115A/X	C7115A/X	C7115A/X	Q5949A/X	Q5949A/X	C8061A/X
Transfer Roller	RG5-4657	RG9-1483	RG9-1483	RG9-1483	RM1-0550	RM1-1471	RM1-1471	RG5-5295
Tray 1 P/U Assembly		RG0-1120	RG0-1120	RG0-1120	RM1-0838			RG5-5084
Tray 1 P/U Roller	RB2-4026	RL1-0303	RL1-0303	RL1-0303	RL1-0303	RL1-0540	RL1-0540	RG5-3718
Tray 1 Sep Pad or Roller	RF5-2886	RF0-1014	RF0-1014	RF0-1014	RF0-1014			RF5-3086
Tray 2 P/U Assembly								RG5-5277
Tray 2 P/U Roller						RL1-0540	RL1-0540	RB1-8957x4
Tray 2 Sep Pad						RM1298	RM1-1298	
Tray 2 Feed/Sep Roller								RF5-3114x2
Tray 3 P/U Assembly								RG5-5293
Tray 3 P/U Roller						RL1-0540	RL1-0540	RB1-8957x4
Tray 3 Sep Pad						RM1-1298	RM1-1298	
Tray 3 Feed/Sep Roller								RF5-3114x2
High Capacity P/U Roller								
High Capacity Feed/Sep								
ADF Parts								
ADF P/U Roller	RG5-5401	C7309-60091	C7309-60091	C7309-60091	C7309-60091	5851-2559	5851-2559	RB2-8769
ADF Sep Roller								RG5-6583
ADF Sep Pad	RY7-5055K	C7309-60076	C7309-60076	C7309-60076	C7309-60076	Q2665-60125	Q2665-60125	RF5-3808
ADF Input Tray		C9143-60102	C9143-60102	C9143-60102	C9143-60102	Q6500-60119	Q6500-60119	RG5-6579
ADF Assembly		C9143-60109	C9143-60109	C9143-60109	C9143-60109	Q6500-67903	Q6500-67903	RG5-6549
Flatbed Scanner		C9124-60103	C9124-60103	C9124-60103	Q2660-60143	Q6500-67902	Q6500-67902	

HP Monochrome MFP Printer Parts

Description	4101MFP	4345MFP	8100MFP	8150MFP	8550MFP	9000MFP	9040MFP	9050MFP
Control Panel	RG5-6563	Q3942-60102	C4166-69102	C4166-69102	FG6-5843	RG5-5734	5851-2462	5851-2462
DC Controller		RM1-1354	RG5-4375	RG5-4375	FG2-9470	RG5-5778	RG5-7780	RG5-7780
Delivery Assembly	RG5-5094	RM1-1047	RG5-1874	RG5-1874	RG0-0110	RG5-5643	RG5-5643	RG5-5643
Delivery Roller								
Drive (Main)	RG5-5087	RM1-1049	RG5-4365	RG5-4365	RG5-3066			
(Delivery)	RG5-5095				RG53067	RG5-5659		
(Fuser)		RM1-0043					RG5-7789	RG5-7789
Engine Controller	RG5-5359							
Formatter (Base)	C7844-67901		C4107-67901	C4265-67901	C7096-69005	C8523-69012		
(Network)		Q3942-69011					Q3726-69007	Q3726-69007
Fuser	RG5-5063	RM1-1043	RG5-6532	RG5-6532	RG5-3060	RG5-5750	RG5-5750	RG5-5750
Laser Scanner	RG5-5100	RM1-1573	RG5-4344	RG5-4344	RG5-3936	RG5-5856	RG5-5856	RG5-5856
LIU	Q1314-69003	Q3701-60012					Q3701-60012	Q3701-60012
Main Motor	RH7-1504	RK2-0273	RH7-5219	RH7-5219		RH7-1656	RH7-1656	RH7-1656
Maintenance Kit	C8057AK	Q5998-67901	C3914AK	C3914AK		C9152-	C9152-	C9152-
Power Supply High			RG5-4306	RG5-4306	RG5-3936	RG5-5728	RG5-5728	RG5-5728
Power Supply Low		RM1-1041	RG5-4357	RG5-4357	RG9-1445	RG5-5730	RG5-5730	RG5-5730
Registration	RG5-5085	RM1-1098	RG5-4303	RG5-4303	RG5-3009	RG5-5663	RG5-5663	RG5-5663
Service Manual	C9148-90909	Q3942-90950	C1265-90963	C1265-90963		C8549-90955	C8549-90955	C8549-90955
Toner	C8061A/X	Q5945A	C4182X	C4182X	C4149/50/51/52	C8534X	C8534X	C8534X
Transfer Roller	RG5-5295	RM1-1110	RF9-1394	RF9-1394	C4154A-kit	RF5-3319	RF5-3319	RF5-3319
Tray 1 P/U Assembly	RG5-5084		RG5-4330	RG5-4330	RG5-3054	RG5-5809	RG5-5809	RG5-5809
Tray 1 P/U Roller	RG5-3718	RL1-0019	RB1-2596	RB1-2596	RB-9526	RF5-3403x2	RF5-3403x2	RF5-3403x2
Tray 1 Sep Pad or Roller	RF5-3086	RL1-0007	RF5-2703	RF5-2703	RF5-1589			
Tray 2 P/U Assembly	RG5-5277	RM1-1034	RG5-4334	RG5-4334	RG5-3132	RG5-5681	RG5-5681	RG5-5681
Tray 2 P/U Roller	RB1-8957x4	RM1-0036	RF5-2708	RF5-2708	RF5-1835	RF5-3340	RF5-3340	RF5-3340
Tray 2 Sep Pad								
Tray 2 Feed/Sep Roller	RF5-3114x2	RM1-0037x2	RF5-1834x2	RF5-1834x2	RF5-1834x2	RF5-3338x2	RF5-3338x2	RF5-3338x2
Tray 3 P/U Assembly	RG5-5293		RG5-4334	RG5-4334	RG5-3132	RG5-5681	RG5-5681	RG5-5681
Tray 3 P/U Roller	RB1-8957x4	RM1-0036	RF5-2708	RF5-2708	RF5-1835	RF5-3340	RF5-3340	RF5-3340
Tray 3 Sep Pad								
Tray 3 Feed/Sep Roller	RF5-3114x2	RM1-0037x2	RF5-1834x2	RF5-1834x2	RF5-1834x2	RF5-3338x2	RF5-3338x2	RF5-3338x2
High Capacity P/U Roller			RF5-2708	RF5-2708		RF5-3338	RF5-3338	RF5-3338
High Capacity Feed/Sep			RF5-1834x2	RF5-1834x2		RF5-3338x2	RF5-3338x2	RF5-3338x2
ADF Parts								
ADF P/U Roller	RB2-8769	PF2282K039NI	PA03002-C120FJ	PA03002-C120FJ	FM6-2145	RG5-6283	RG5-6283	RG5-6283
ADF Sep Roller	RG5-6583							
ADF Sep Pad	RF5-3808	PF2282K035NI	PA03002-C122FJ	PA03002-C122FJ	FG6-2176	RG5-6281	RG5-6281	RG5-6281
ADF Input Tray	RG5-6579	PF2282K042NI	PA03002-C104FJ	PA03002-C104FJ	FM6-0276			
ADF Assembly	RG5-6549	PF2282-SVPNR						
Flatbed Scanner		IR4041-SVPNR	PA03002-C219FJ	PA03002-C219FJ	85501538WER	RG5-6263	RG5-6263	RG5-6263

HP Monochrome MFP Printer Parts

Description	9055MFP	9065MFP	9085MFP	M1005	M1120	M1132	M1212/M1217*	M1319
Control Panel	56NE-7000KC	56NE-7000KC	Q5681A	CB376-60101	CB53760109	CE841-60107	CE841-60110	RM1-5178
DC Controller			55VA84511KC					
Delivery Assembly								
Delivery Roller								
Drive (Main)								
(Delivery)								
(Fuser)								
Engine Controller			45029123EF	RM1-3943	RM1-4932	RM1-7892	RM1-7892	RM1-3404
Formatter (Base)				CB397-60001	CC390-60001	CE831-60001	CE832-60001	CC391-60001
(Network)					CC427-60001			
Fuser	56AE-53TOKC	56AE-53TOKC	56GA-5201KC	RM1-3952	RM1-4721	RM1-7733	RM1-7733	RM1-5363
Laser Scanner	56AA-6500KC	56AA-6500KC		RM1-2084	RM1-4724	RM1-6878	RM1-6878	RM1-2033
LIU					CC502-60001		CE833-60001	CC392-60001
Main Motor				RK2-0799	RM1-4196	RM1-7895	RM1-7895	RK2-0777
Maintenance Kit			56HK-P5M0KC					
Power Supply High	56AA84011KC	56AA84011KC	55VA84013KC					
Power Supply Low	56AE-7190KC	56AE-7190KC	13LH4511KC	RM1-3941				RM1-5280
Registration			56GB-3600KC					
Service Manual	Q3631-90908	Q3631-90908		CB376-90929	CB537-90945			CB536-90938
Toner	Q3682C	Q3682C	Q5701C	Q2612A	CB436A	CE285A		Q2612A
Transfer Roller			56GA26210KC	RM1-2083	RM1-4234	RM1-4023	RM1-4023	RM1-2062
Tray 1 P/U Assembly			56GB53040KC	RM1-2091	RM1-4727	RM1-7737	RM1-7737	RM1-3043
Tray 1 P/U Roller			129X48421KC	RL1-0266	RL1-1497	RL1-2593	RL1-2593	RL1-0266
Tray 1 Sep Pad or Roller				RL1-0648	RM1-4207	RM1-4006	RM1-4006	RM1-2048
Tray 2 P/U Assembly			55VAR74600KC					
Tray 2 P/U Roller								
Tray 2 Sep Pad								
Tray 2 Feed/Sep Roller								
Tray 3 P/U Assembly			55VAR74900KC					
Tray 3 P/U Roller								
Tray 3 Sep Pad								
Tray 3 Feed/Sep Roller								
High Capacity P/U Roller								
High Capacity Feed/Sep								
ADF Parts								
ADF P/U Roller	13QA-4140KC	13QA-4140KC					CB780-60032	RM1-0885
ADF Sep Roller			13GA46050KC					
ADF Sep Pad	13QA-4120KC	13QA-4120KC					CB780-80008	RM1-0891
ADF Input Tray	U6181-60010	U6181-60010					CE841-60118	RM1-3419
ADF Assembly			Q5682A				CE841-60106	
Flatbed Scanner				CB376-67901	CB537-67901	CE847-60112	CE841-60125	

M217 Wi-Fi Card Included

HP Monochrome MFP Printer Parts

Description	M1522	M1536	M2727	M3027	M3035	M425	M4345	M4555
Control Panel	CB534-60101	CE539-60101	CB532-60101	CB414-60101	CB414-60101	CF286-60601 CF286-60602 Wireless	CB425-67903	CC419-67901
DC Controller						RM1-9308	RM1-1354	RM1-7102
Delivery Assembly							RM1-1047	
Delivery Roller			RL1-0527	RM1-3749	RM1-3749			
Drive (Main)			RM1-4253	RM1-3712	RM1-3712		RM1-1049	
(Delivery)				RM1-3476	RM1-3476			
(Fuser)							RM1-0043	
Engine Controller	RM1-4932	RM1-7629	RM1-4940	RM1-3774	RM1-3774	RM1-9308		
Formatter (Base)	CC396-60001	CE544-60001				CF229-60001		
(Network)	CC368-60001		CC370-60001	Q7819-61009	Q7819-61009		CB425-67910	CE502-69005
Fuser	RM1-4721	RM1-7576	RM1-4247	RM1-3740	RM1-3740	RM1-8808	RM1-1043	RM1-7395
Laser Scanner	RM1-4724	RM1-7560	RM1-4262	RM1-1521	RM1-1521	RM1-9135	RM1-1573	RM1-7419
LIU	CC502-60001	CE682-60001	CC502-60001			CF206-60001	Q3701-60012	
Main Motor	RM1-4196	RM1-7544	RK2-1567	RK2-1489	RK2-1489	RM1-9042	RK2-0273	
Maintenance Kit			P2015MK				Q5998-67901	CE731A
Power Supply High								RM1-7384
Power Supply Low				RM1-3758	RM1-3758		RM1-1041	RM1-7401
Registration			RM1-4244	RM1-3715	RM1-3715	RM1-8806	RM1-1098	RM1-5460
Service Manual	CB534-90945	CE538-90986	CB532-90946	CB414-90940	CB414-90940	CF286-90979	Q3942-90950	CE502-90971
Toner	CB436A	CE278A	Q7553A	Q7551A/X	Q7551A/X	CF280A/X	Q5945A	CE390A/X
Transfer Roller	RM1-4234	RM1-4023	RM1-4279	RM1-1508	RM1-1508	RM1-9175	RM1-1110	RM1-5462
Tray 1 P/U Assembly	RM1-4727	RM1-7575						RM1-7377
Tray 1 P/U Roller	RL1-1497	RL1-1497	RL1-1525	RL1-0568	RL1-0568	RL1-3307	RL1-0019	RL1-1641
Tray 1 Sep Pad or Roller	RM1-4207	RM1-4227	RL1-1524	RC1-0939	RC1-0939	RL1-2115	RL1-0007	RM1-5460
Tray 2 P/U Assembly				RM1-3762	RM1-3762		RM1-1034	RM1-5919
Tray 2 P/U Roller			RL1-0540	RL1-1370	RL1-1370	RM1-9168	RM1-0036	RL1-2099
Tray 2 Sep Pad			RM1-1298	RM1-3738	RM1-3738	RM1-7365		
Tray 2 Feed/Sep Roller							RM1-0037x2	RM1-0037x2
Tray 3 P/U Assembly								RM1-5929
Tray 3 P/U Roller			RL1-0540	RL1-1370	RL1-1370		RM1-0036	RL1-2099
Tray 3 Sep Pad			RM1-1298	RM1-3738	RM1-3738			
Tray 3 Feed/Sep Roller							RM1-0037x2	RM1-0037x2
High Capacity P/U Roller								RL1-2099
High Capacity Feed/Sep								RM1-0037x2
ADF Parts								
ADF P/U Roller	5851-2559	CE538-60137	5851-2559	CB414-67904	CB414-67904	CF288-60015	PF2282K039NI	PF2309K131NI
ADF Sep Roller						CF288-60016		
ADF Sep Pad	Q2665-60125		Q2665-60125			CF288-60021	PF2282K035NI	PF2309K133NI
ADF Input Tray	CB534-60112	CE538-60127	Q6500-60119	CB414-67903	CB414-67903		PF2282K042NI	PF2309K106NI
ADF Assembly	CB534-67901	CE538-60121	CB532-67903	CB414-67928*	CB414-67928*	CF288-60011	PF2282-SVPPNR	
Flatbed Scanner	CB534-67903	CE538-60118	CB532-67905	CB414-67921*	CB414-67921*	CF288-60105	IR4041-SVPPNR	IR4070-SVP

*CB414-67928 (ADF) CB414-67921 (Flatbed) are Letter Size *CC476-67913 (ADF) CC476-67911 (Flatbed) are Legal Size for 3027/3035

HP Monochrome MFP Printer Parts

Description	M5025	M5035	M521	M525	M525C	M725	M9040/9050
Control Panel	Q7829-60102	Q7829-60102	A8P79-60115	CD644-67916	CD644-67920	CD644-67916	CC395-60102
DC Controller	RM1-3459	RM1-3459	RM1-8615	RM1-8615	RM1-8615		RG5-7780
Delivery Assembly	RM1-2987	RM1-2987					RG5-5643
Delivery Roller			RM1-6301	RM1-6301	RM1-6301		
Drive (Main)	RL1-0951	RL1-0951					
(Delivery)							
(Fuser)	RM1-2963	RM1-2963					RG5-7789
Engine Controller							
Formatter (Base)						CF066-67901	
(Network)	Q7565-67910	Q7565-67910	A8P79-60001	CF104-69001	CF105-69001		CC395-67902
Fuser	RM1-3007	RM1-3007	RM1-8508	RM1-8508	RM1-8508		RG5-5750
Laser Scanner	RM1-2555	RM1-2555	RM1-6322	RM1-6322	RM1-6322		RG5-5856
LIU			CF116-67904	CF116-67904	CF116-67904	CF066-67912	Q3701-60012
Main Motor	RM1-2516	RM1-2516					RH7-1656
Maintenance Kit			CF116-67903	CF116-67903	CF116-67903		C9152-69002
Power Supply High	RM1-2957	RM1-2957	RM1-8519	RM1-8519	RM1-8519		RG5-5728
Power Supply Low	RM1-2994	RM1-2994	RM1-8514	RM1-8514	RM1-8514		RG5-5730
Registration	RM1-3001	RM1-3001	RM1-8507	RM1-8507	RM1-8507		RG5-5663
Service Manual	Q7543-90908	Q7543-90908				CF066-90988	C8549-90955
Toner			CE255A/X	CE255A/X	CE255A/X	CF214A/X	C8534X
Transfer Roller	RM1-2485	RM1-2485	RM1-6321	RM1-6321	RM1-6321	CF235-67910	RF5-3319
Tray 1 P/U Assembly							RG5-5809
Tray 1 P/U Roller	RL1-0915	RL1-0915	RL1-2412	RL1-2412	RL1-2412	CF235-67906 Kit	RF5-3403x2
Tray 1 Sep Pad or Roller	RM1-2462	RM1-2462	RC2-8575	RC2-8575	RC2-8575	Included in T1 Kit	
Tray 2 P/U Assembly	RM1-2976	RM1-2976	RM1-8505	RM1-8505	RM1-8505	RM2-0182	RG5-5681
Tray 2 P/U Roller	RM1-2988	RM1-2988	RM1-6323	RM1-6323	RM1-6323	CF235-67909 Kit	RF5-3340
Tray 2 Sep Pad	RM1-2983	RM1-2983	RM1-6303	RM1-6303	RM1-6303	Included in T2/3 Kit	
Tray 2 Feed/Sep Roller							RF5-3338x2
Tray 3 P/U Assembly	RM1-2977	RM1-2977				RM2-0183	RG5-5681
Tray 3 P/U Roller	RM1-2988	RM1-2988	RM1-6306	RM1-6306	RM1-6306	Included in T2/3 Kit	RF5-3340
Tray 3 Sep Pad	RM1-2983	RM1-2983	RM1-6303	RM1-6303	RM1-6303	Included in T2/3 Kit	
Tray 3 Feed/Sep Roller							RF5-3338x2
High Capacity P/U Roller						CC522-67909	RF5-3338
High Capacity Feed/Sep							RF5-3338x2
ADF Parts							
ADF P/U Roller	Q7842-67902 Kit	Q7842-67902 Kit	A8P76-65001	L2725-60002 Kit	L2725-60002 Kit	L2725-60002 Kit	RG5-6283
ADF Sep Roller			A8P79-65010				
ADF Sep Pad							RG5-6281
ADF Input Tray	Q7829-67912	Q7829-67912					
ADF Assembly	Q7829-67901	Q7829-67901	A8P79-60120	CF116-67910	CF116-67922	CF066-67910	
Flatbed Scanner	Q7829-60159	Q7829-60159	A8P79-60121	CF116-67918	CF116-67924	CF066-67906	RG5-6263

HP Color Laser Jet Printer Parts

Description	1500	1600	2500	2550	2600	2605	3000	3500	3550	3600
Control Panel	RG5-6297	RM-1983	RG5-6297	RG5-7570	RM1-1983	RM1-1861	RK2-0996	RM1-0511	RM1-0511	RK2-0989
DC Controller	RG5-6959	RM1-1975	RG5-6959	RG5-7611	RM1-1975	RM1-3423	RM1-2600	RM1-0510	RM1-0510	RM1-2580
(Duplex)										
Drive Assembly (Main)	RG5-6392		RG5-6932	RG5-7579			RM1-2751			RM1-2751
(Delivery or Fuser)							RM1-2668			RM1-2668
(Drum)										
(Carousel)	RG5-6911		RG5-6911	RG5-7842						
Firmware			C9168CC				CB399-67904 N			
Formatter (Duplex)										
(Base/Simplex)	Q1894-60001		C9145-69001	Q3702-69001		Q7803-60002	Q5982-69001 N	Q1319-67902	Q1319-67902	
(Network)				Q3703-69001	Q5965-67901	Q5966-60001	Q5982-69001			Q5987-67903
(Wireless)										
Fuser	RG5-6903	RM1-1820	RG5-6903	RG5-7572	RM1-1820	RM1-1828-(S)	RM1-2665	RM1-0428	RM1-0428	RM1-2665
Fuser Kit						RM1-1824-(D)		Q3655A	Q3655A	
Image Drum	C9704A		C9704A	Q3964A						
Laser Scanner	RG5-6880		RG5-6880	RG5-6880	RM1-1970	RM1-3492	RM1-2952	RM1-1480	RM1-1480	RM1-2640
Manual	C9706-90926		C9706-90926	Q3702-90923	Q6455-90930	Q7821-90930	Q5982-90932	Q1321-90930	Q1321-90930	Q5982-90932
HVPS Image (D)	RG5-6960		RG5-6960	RG5-7647	RM1-1978		RM1-2578	RM1-0505	RM1-0505	RM1-2578
HVPS Secondary (T)										
Power Supply Low	RH3-2252		RH3-2252	RH3-2262	RM1-1976		RM1-4377	RK2-0157	RK2-0157	RM1-4377
Registration (Simplex)				RG5-6939						
(Duplex)										
Toner (B)	C9700A	Q6000A	C9700A	Q3960A	Q6000A	Q6000A	Q7560A	Q2670A	Q2670A	Q6470A
(C) (Y) (M) *	01*02*03*	01*02*03*	01*02*03*	61*62*63*	01*02*03*	01*02*03*	61*62*63*	70*72*73*	71*72*73*	Q7581*2*3
Transfer Kit (Simplex)		RM1-1885			RM1-1885	RM1-1891-(S)	RM1-2759(S)	Q3658A	Q3658A	RM1-2759(S)
(Duplex)						RM1-1892-(D)	RM1-2752(D)			RM1-2752(D)
Transfer Roller	RF5-4040		RF5-4040	RF5-4067						
Tray 1 P/U Assembly	RG5-6952		RG5-6952	RG5-6952			RM1-2774	RM1-0765	RM1-0765	RM1-2755
Tray 1 Roller	RB3-0160		RB3-0160	RB3-0160			RM1-2741	RC1-1535	RC1-1535	RM1-2741
Tray 1 Sep Pad	RF5-4012		RF5-4012	RF5-4012			RM1-2699	RM1-0739	RM1-0739	RM1-2699
Tray 2 P/U Assembly							RM1-2774	RM1-0765	RM1-0765	RM1-2755
Tray 2 Roller	RB3-0161		RB3-0161	RB3-0161	RC1-5440	RC1-5440	RM1-2702	RM1-0731	RM1-0731	RM1-2702
Tray 2 Sep Pad	RF5-4258		RF5-4258	RF5-4258	RM1-1922	RM1-1922	RM1-2709	RC1-0954	RC1-0954	RM1-2709
Tray 2 Feed/Sep Roller										
Tray 3 P/U Assembly										
Tray 3 Roller	RB3-0161		RB3-0161	RB3-0161	RC1-5440	RC1-5440	RM1-2727			RM1-2727
Tray 3 Sep Pad	RF5-4258		RF5-4258	RF5-4258	RM1-1922	RM1-1922	RM1-2735			RM1-2735
Tray 3 Feed/Sep Roller										

HP Color Laser Jet Printer Parts

Description	3700	3800	4500JPG <	4500JPH-JPZ	4550	4600	4650	4700	5500
Control Panel	RM1-0511	RK2-0989	RG5-5200	RG5-5200	RG5-5200	RG5-6432	RG5-7489	RM1-1617	RG5-6781
DC Controller	RM1-0506	RM1-2580	RG5-3809	RG5-5254	RG5-5254	RG5-6391	RG5-7470	RM1-1607	RG5-6850
(Duplex)									
Drive Assembly (Main)		RM1-2751						RM1-1716	
(Delivery or Fuser)		RM1-2668	RG5-5135	RG5-5135	RG5-5135	RG5-6512	RG5-7452	RM1-1729	RG5-6714
(Drum)			RG5-5206	RG5-5206	RG5-5206				
(Carousel)			RG5-5502	RG5-5502	RG5-5502				
Firmware	Q3992-67906	CB399-67903	C4084-60007	C4084-60007	C9130-67906	C9712-67918	Q7725-67937	Q7725-67926	C9712-67922
Formatter (Duplex)	Q1321-69002	Q5982-69002	C4084-67905	C4084-67905		C9661-69002	Q3999-69002		C9661-69002
(Base/Simplex)	Q1321-69002	Q5982-69001				C9660-69001	Q3999-69002	Q7491-69003	C9660-69001
(Network)					C4227-69001			Q7492-69003	
(Wireless)									
Fuser	RM1-0428	RM1-2665	RG5-5154	RG5-5154	RG5-5154	RG5-6493	RG5-7450	RM1-3131	RG5-6848
Fuser Kit	Q3655A		C4197A	C4197A	C4197A	C9725A	Q3676A	Q7502A	C9735A
Image Drum			C4195A	C4195A	C4195A				
Laser Scanner	RM1-1480	RM1-2640	RG5-5175	RG5-5175	RG5-5175	RG5-6390	RG5-7475	RM1-1591	RG5-6736
Manual	Q5990-90935	Q5982-90932	C7085-90921	C7085-90921	C7085-90921	C9660-90901	Q3668-90970	Q7491-90932	C9656-90930
HVPS Image (D)	RM1-0505	RM1-2578	RG5-3285	RG5-5165	RG5-5165	RG5-6395	RG5-6395	RM1-1608	RG5-7985
HVPS Secondary (T)									
Power Supply Low	RK2-0157	RM1-4377	RH3-2219	RH3-2219	RH3-2219	RG5-6410	RG5-6410	RK2-0627	RG5-6808
Registration (Simplex)									
(Duplex)									
Toner (B)	Q2670A	Q6470A	C4191A	C4191A	C4191A	C9720A	C9720A	Q5950A	C9730A
(C) (Y) (M) *	Q2681*2*3*	Q7581*2*3	92*93*94*	92*93*94*	92*93*94	21*22*23*	21*22*23*	51*52*53*	31*32*33*
Transfer Kit (Simplex)	Q3658A	RM1-2759(S)	C4196A	C4196A	C4196A	Q3675A	Q3675A	Q7504A	C9734B
(Duplex)		RM1-2752(D)							
Transfer Roller			RF5-2112	RF5-2112	RF5-2112				
Tray 1 P/U Assembly	RM1-0741	RM1-2755				RG5-6468	R55-7453		RG5-6670
Tray 1 Roller	RC1-1535	RM1-2741	RB2-0717	RB2-0717	RB2-0717	RG9-1529	RG9-1529	RL1-0019	RG9-1529
Tray 1 Sep Pad	RM1-0739	RM1-2699	RB2-0744	RB2-0734	RB2-0734	RG5-3750	RF5-3750	RF5-3750	RF5-3865
Tray 2 P/U Assembly	RM1-0741	RM1-2755				RG5-6468	RG5-7453		RG5-6670
Tray 2 Roller	RM1-0731	RM1-2702	RF5-2092	RF5-2092	RF5-2092	RF5-3739x2	RF5-3739x2	RM1-0036	RF5-3340
Tray 2 Sep Pad	RC1-0954	RM1-2709							
Tray 2 Feed/Sep Roller			RF5-1885	RF5-1885	RF5-1885			RM1-0037x2	RF5-3338x2
Tray 3 P/U Assembly	RM1-0701								RG5-6748
Tray 3 Roller	RM1-0731	RM1-2727	RF5-1885	RF5-1885	RF5-1885	RF5-3739x2	RF5-3739x2	RM1-0036	RF5-3340
Tray 3 Sep Pad	RM1-0827	RM1-2735							
Tray 3 Feed/Sep Roller			RF5-1885	RF5-1885	RF5-1885			RM1-0037x2	RF5-3338x2

HP Color Laser Jet Printer Parts

Description	5550	8500	8550	9500	CP1215	CP1518	CP2025/CP2035	CP3505	CP3525
Control Panel	RG5-6781	RG0-0116	RG0-0116	RG5-7900	RM1-4468	RM1-4469	RM1-4832	RK2-0989	RM1-5743
DC Controller	RM1-3812	RG5-3037	RG5-3037	RG5-6200	RM1-4813	RM1-4811	RM1-5431	RM1-2580	RM1-5678
(Duplex)									
Drive Assembly (Main)		RG5-3066	RG5-3066				CM2320-GT	RM1-2751	CC468-67918
(Delivery or Fuser)	RG5-7700	RG5-3067	RG5-3067	RG5-6018				RM1-2668	Call Tech
(Drum)		RG5-3065	RF5-3065	RG5-6188					RM1-4988
(Carousel)		RG5-3065	RG5-3065						
Firmware	Q7725-67939			C9712-67923					
Formatter (Duplex)	Q3713-69002								
(Base/Simplex)	Q3713-69002	C3983-69001	C7096-67905		CB505-60001			CB441-69001	
(Network)				C8546-69001		CB479-60001	CB492-60002		CE859-69002
(Wireless)									
Fuser	RG5-7691	RG5-3060	RG5-3060	RG5-6098	RM1-4430	RM1-4430	RM1-6740	RM1-2665	RM1-4955
Fuser Kit	Q3984A	C4155A	C4155A	C8556A					CE484A
Image Drum		C4153A	C4153A						
Laser Scanner	RG5-7681	RG5-3936	RG5-3936	RG5-6181	RM1-4766	RM1-4766	RM1-5308	RM1-2640	RM1-5676
Manual	Q3713-90965	C7086-90967	C7096-90986	C8546-91012		CC378-90983	Q7517-91020	Q5982-90932	CC468-90963
HVPS Image (D)	RG5-7985	RG5-3943	RG5-3943	RG5-7901	RM1-4689	RM1-4689	RM1-5294	RM1-2578	RM1-5680
HVPS Secondary (T)									RM1-5681
Power Supply Low	RG5-6808	RG9-1445	RG9-1445	RH3-2258	RM1-4815	RM1-4815	RM1-5407	RM1-4377	RM1-5685
Registration (Simplex)		RG5-3009	RG5-3009	RG5-6016					RM1-5009
(Duplex)									RM1-4969
Toner (B)	C9730A	C4149A	C4149A	C8550A	CB540A	CB540A	CC530A	Q6470A	CE250A
(C) (Y) (M) *	31*32*33*	50*51*52*	50*51*52*	1*2*3*	01*02*03	01*02*03	31*32*33*	Q7581*2*3	51*52*53*
Transfer Kit (Simplex)	C9734B	C4154A	C4154A	C8555A	RM1-4436	RM1-4436	RM1-4852	RM1-2759(S)	CC468-67927
(Duplex)								RM1-2752(D)	
Transfer Roller				RG5-6178	RM1-4445	RM1-4445			CC468-67914
Tray 1 P/U Assembly	RG5-7709	RG5-3054	RG5-3054	RG5-6090			RM1-4839	RM1-2755	Call Tech
Tray 1 Roller	RG9-1529	RB1-9526	RB1-9526	RB2-1820		RM1-4526	RL1-1802	RM1-2741	RL1-1928
Tray 1 Sep Pad	RF5-3865	RF5-1989	RF5-1989	RF5-3490		RM1-4525	RL1-1785	RM1-2699	RL1-1937
Tray 2 P/U Assembly	RG5-7709	RG5-3132	RG5-3132	RG5-6196				RM1-2755	RM1-4967
Tray 2 Roller	RF5-3340	RF5-1835	RF5-1835	RF5-3340	RM1-4426	RM1-4526	RM1-4426	RM1-2702	RM1-4968
Tray 2 Sep Pad								RM1-2709	
Tray 2 Feed/Sep Roller	RF5-3338x2	RF5-1834x2	RF5-1834x2	RF5-3338x2	RM1-4425	RM1-4525	RM1-4840		RM1-4966
Tray 3 P/U Assembly	RG5-6748	RG5-3132	RG5-3132	RG5-6196					
Tray 3 Roller	RF5-3340	RF5-1835	RF5-1835	RF5-3340				RM1-2727	RL1-2099
Tray 3 Sep Pad								RM1-2735	
Tray 3 Feed/Sep Roller	RF5-3338x2	RF5-1834x2	RF5-1834x2	RF5-3338x2					RM1-0037x2

HP Color Laser Jet Printer Parts

Description	CP4005	CP4025	CP4525	CP5225	CP5525	CP6015	M251	M351/M451	M551
Control Panel	RM1-1617	RM1-5786	RM1-5786	RM1-7145	RM1-7144	RM1-4516	Call Tech	RM1-8040	RM1-8096
DC Controller	RM1-1607	RM1-5758	RM1-5758	RM1-6796	CE707-67906	Q3931-67930	RM1-8704	RM1-8039	RM1-8104
(Duplex)				RM1-6639	CE708-67902				
Drive Assembly (Main)	RM1-1716	CC493-67915	CC493-67915	Call tech	Call tech	Q3931-67911	RM1-9328		CF081-67910
(Delivery or Fuser)	RM1-1729			RM1-6076	RM1-6076	RM1-4519	RM1-8784	RM1-8049	Call Tech
(Drum)									
(Carousel)									
Firmware	Q7725-67942								
Formatter (Duplex)	CB503-67901					Q7539-69004			
(Base/Simplex)									
(Network)	CB503-67901	CC493-69001	CC493-69001	CE490-67901	CE707-690002	Q7539-69003	CF152-60001	CE794-60001	CF081-69001
(Wireless)							CF153-60001	RM1-7038	
Fuser	RM1-3131	CC493-67911	CC493-67911	CE710-69001	CE707-67912	RM1-3242	RM1-8780	RM1-8054	CF081-67905
Fuser Kit	Q7502A	CE246A	CE246A			CB457A			
Image Drum						CB384*5*6*7			
Laser Scanner	RM1-1591	CC493-67914	CC493-67914	RM1-6122	RM1-6122	Q3931-67907			CC468-67917
Manual	Q7491-90932	CC489-90936	CC489-90936	CE710-90910	CE710-90910		CF146-90961	CE955-90964	CF079-90942
HVPS Image (D)	RM1-1608	RM1-5779	RM1-5779	RM1-6800	RM1-6800	RM1-3582	RM1-8705	RM1-8031	RM1-8087
HVPS Secondary (T)		RM1-5781	RM1-5781	RM1-6802	RM1-6802	RM1-5475			Call Tech
Power Supply Low	RK2-0627	RM1-5763	RM1-5763	RM1-6755	RM1-6753	RM1-3594	Call Tech	RM1-8035	RM1-8091
Registration (Simplex)		CC493-67916	CC493-67916			Q3931-67909		RM1-4841	Call Tech
(Duplex)		CC493-67917	CC493-67917						
Toner (B)	CB400A	CE260A	CE260A	CE740A	CE740A	CB380A	CF210-67901	CE410-67901	CE400-67901
(C) (Y) (M) *	01*02*03*	61*62*63*	61*62*63*	41*42*43*	41*42*43*	01*02*03*	11*12*13*	11*12*13*	01*02*03*
Transfer Kit (Simplex)	Q7504A	CC493-67909	CC493-67909	CE710-69003	CE710-69003	RM1-3307	RM1-8777	RM1-4852	CF081-67904
(Duplex)									
Transfer Roller		CC493-67908	CC493-67908	CE710-69004	CE710-69004	Q3931-67910	RM1-4445		CC468-67914
Tray 1 P/U Assembly	RM1-2199			Call Tech	Call Tech	RM1-3345		RM1-8610	Call Tech
Tray 1 Roller	RL1-0019	CC493-67906	CC493-67906	CE710-69006	CE710-69006	RC1-8567		RL1-1802	RL1-1928
Tray 1 Sep Pad	RF5-3750	RL1-1937	RL1-1937	CE710-69006	CE710-69006			RL1-1785	RL1-1937
Tray 2 P/U Assembly		RM1-5919	RM1-5919	Call tech	RM1-7916	RM1-3206			Call Tech
Tray 2 Roller	RM1-0036	RL1-2099	RL1-2099	RM1-6035	RM1-6035	RL1-1289	RM1-8047		RM1-8131
Tray 2 Sep Pad								RM1-4426	
Tray 2 Feed/Sep Roller	RM1-0037x2	RM1-0037x2	RM1-0037x2	RM1-6010	RM1-6010	RM1-0037x2	RM1-8765	RM1-4840	RM1-8129
Tray 3 P/U Assembly				RM1-6944	RM1-6944				RM1-5919
Tray 3 Roller	RM1-0036	RL1-2099	RL1-2099	RL1-1206	RL1-1206	RL1-1289			RL1-2099
Tray 3 Sep Pad									
Tray 3 Feed/Sep Roller	RM1-0037x2	RM1-0037x2	RM1-0037x2	RM1-0037x2	RM1-0037x2	RM1-0037x2			RM1-0037x2

HP Color MFP Printer Parts

Description	1015	1017	2820	2830	2840	4730	9500	CM1312
Control Panel	CB394-60101	CB395-60101	Q3948-60111	Q3949-60134	Q3949-60134	Q7517-60132	5851-2462	CC431-60101
DC Controller	RM1-4366	RM1-4366	RG5-7646	RG5-7646	RG5-7646	RM1-2346	RG5-6200	RM1-5313
Delivery Assembly	RM1-4312	RM1-4312				RM1-1730	RG5-6017	
Deliver Roller	RC2-1682	RC2-1682	RG5-7637	RG5-7637	RG5-7637			
Drive (Main)	RM1-1895	RM1-1895	RG5-7579	RG5-7579	RG5-7579	RM1-2137		
(Delivery)								
(Fuser)						RM1-1729	RG5-6018	
Engine Controller								
Formatter Base	CB394-67902	CB395-67902	Q3948-69001				Q7509-69001	CC397-60001
Network and/or Fax Model				Q3948-69006	Q3948-69006	Q7517-69006		CC398-60001
Wireless								
Fuser	RM1-4310	RM1-4310	RG5-7602	RG5-7602	RG5-7602	RM1-3131	C8556A	RM1-4430
Image Drum								
Laser Scanner			RG5-6890	RG5-6890	RG5-6890	RM1-1591	RG5-6181	RM1-4766
LIU/Fax Card						Q3701-60012	Q3701-60012	CC367-60001
Main Motor			RF5-4063	RF5-4063	RF5-4063			
Maintenance Kit								
Power Supply High/Upper			RG5-7647	RG5-7647	RG5-7647	RM1-1608	RH3-0353	RM1-4689
Power Supply High/Lower								
Power Supply Low			RH3-2260	RH3-2260	RH3-2260	RK2-0627	RH3-2258	RM1-5315
Registration							RG5-6016	
Service Manual			Q3948-90943	Q3948-90943	Q3948-90943	Q7517-91020	C8549-90955	CC430-90964
Toner (B)		Q6000A	Q3960A	Q3960A	Q3960A	Q6460A	C8550A	CB540A
(C) (Y) (M) *		1*2*3*	1*2*3*	1*2*3*	1*2*3*	1*2*3*	1*2*3*	1*2*3*
Transfer Kit								
Transfer Roller			RF5-4067	RF5-4067	RF5-4067	Q7504A	RG5-6178	RM1-4445
Tray 1 P/U Assembly						RM1-2199	RG5-6090	
Tray 1 P/U Roller			RB3-0160	RB3-0160	RB3-0160	RL1-0019	RB2-1820	RM1-4426
Tray 1 Sep Pad			RF5-4012	RF5-4012	RF5-4012	RF5-3750		RM1-4425
Tray 2 P/U Assembly	RM1-1923	RM1-1923					RG5-6196	
Tray 2 P/U Roller	RC1-5440	RC1-5440	RB3-0161	RB3-0161	RB3-0161	RM1-0036	RF5-3340	
Tray 2 Sep Pad	RM1-1922	RM1-1922	RF5-4258	RF5-4258	RF5-4258			
Tray 2 Feed/Sep Roller						RM1-0037x2	RF5-3338x2	
Tray 3 P/U Assembly	Q6459-67902	Q6459-67902					RG5-6196	
Tray 3 P/U Roller			RB3-0161	RB3-0161	RB3-0161	RM1-0036	RF5-3340	
Tray 3 Sep Pad			RF5-4258	RF5-4258	RF5-4258			
Tray 3 Feed/Sep Roller						RM1-0037x2	RF5-3338x2	
High Capacity P/U Roller							RG5-3338	
High Capacity Feed/Sep							RF5-3338x2	
ADF Parts								
ADF Maintenance Kit								
ADF P/U Roller			Q3948-67904	Q3948-67904	Q3948-67904	PF2282K039NI	RG5-6283	5851-2559
ADF Sep Roller								
ADF Sep Pad			Q2665-60125	Q2665-60125	Q2665-60125	PF2282K035NI	RG5-6281	
ADF Input Tray			Q3948-60214	Q3948-60214	Q3948-60214	PF2282K042NI		CC431-60119
ADF Assembly			Q3948-60189	Q3948-60189	Q3948-60189	PF2288-SVPNR		CC431-60131
Flatbed Scanner	CB394-67901	CB395-67901	Q3948-60191	Q3948-60191	Q3948-60191	IR4054-SVPNI	RG5-6263	CC431-60113

HP Color MFP Printer Parts

Description	CM1415	CM2320	CM3530	CM4540	CM4730	CM6030/6040	M175	M275
Control Panel	CE862-60101	CC431-60101	CC519-60115	CC419-67901	CB480-60126	Q3938-67963	CE865-60106	CF039-60101
DC Controller	RM1-7813	RM1-5431	RM1-5678	RM1-5785	RM1-2346	RM1-6642		
Delivery Assembly		RM1-4873	RM1-4970	RM1-5615	RM1-1730	RM1-3293		
Deliver Roller								
Drive (Main)		CM2320-GT	CC468-67918	CC493-69003	RM1-2137	Q3931-67911		
(Delivery)						RM1-3340		
(Fuser)	RM1-4927		RM1-4974		RM1-1729			
Engine Controller							RM1-8205	RM1-8205
Formatter Base		CC399-67901				Q3938-67982		
Network and/or Fax Model	CE690-67901	CC400-67901	CC452-60001	CE871-69003	Q7517-69006		CE865-60001	CD669-60001
Wireless	1150-7938						CE938-60001	1150-7940
Fuser	RM1-4430	RM1-6740	RM1-4955	CC493-67911	RM1-3131	RM1-3242	RM1-7211	RM1-7211
Image Drum							CE314-67901	CE314-67901
Laser Scanner		RM1-5308	CC468-67917	CC493-67914	RM1-1591	Q3931-67907		
LIU/Fax Card	CE382-67901	CC367-60001	CC456-60001	CC456-60002	Q3701-60012	Q3701-60020		
Main Motor	RM1-1834	RM1-5417						
Maintenance Kit								
Power Supply High/Upper	RM1-7090	RM1-5294	RM1-5680 (A)	RM1-5781	RM1-1608	RM1-3582 (A)		
Power Supply High/Lower								
Power Supply Low	RM1-7830	RM1-5409	RM1-5689	RM1-5763	RK2-0627	RM1-3594	RM1-8203	RM1-8203
Registration			RM1-4969					
Service Manual	CE861-40939	CC434-90969	CC519-91013		Q7517-91020	Q3938-90953	CE865-90968	CF040-90969
Toner (B)	CE320A	CC530A	CE250A	CE264A/X	Q6460A		CE310-37901	CE310-67901
(C) (Y) (M) *	1*2*3*	1*2*3*	1*2*3*	CF031*032*033	1*2*3		311*312*313*	311*312*313*
Transfer Kit	RM1-7866			CE249A			RM1-7274	RM1-7274
Transfer Roller	RM1-4445		CC468-67914	CC493-67908	Q7504A	RM1-3319		
Tray 1 P/U Assembly		RM1-4839		RM1-5549	RM1-2199	RM1-3345		
Tray 1 P/U Roller		RL1-1802	RL1-1928	CC493-67906	RL1-0019	Q3931-67920	RL1-2671	RL1-2671
Tray 1 Sep Pad				RL1-1937	RF5-3750		RM1-7228	RM1-7228
Tray 2 P/U Assembly			RM1-4967			RM1-3206		
Tray 2 P/U Roller	RM1-4426	RM1-4426	RM1-4968	RL1-2099	RM1-0036	RL1-1289		
Tray 2 Sep Pad		RL1-1785						
Tray 2 Feed/Sep Roller	RM1-4425	RM1-4840	RM1-4966	RM1-0037x2	RM1-0037x2	RM1-0037x2		
Tray 3 P/U Assembly								
Tray 3 P/U Roller			RL1-2099	RL1-2099	RM1-0036	RL1-1289		
Tray 3 Sep Pad								
Tray 3 Feed/Sep Roller			RM1-0037x2	RM1-0037x2	RM1-0037x2	RM1-0037x2		
High Capacity P/U Roller						RL1-1289		
High Capacity Feed/Sep						RM1-0037x2		
ADF Parts								
ADF Maintenance Kit			CC519-67909					
ADF P/U Roller	CE538-30137	5851-3580		PF2309K131NI	PF2282K039NI	Q3938-67954	CE538-60137	
ADF Sep Roller				PF2309K133NI				
ADF Sep Pad	Q7400-60153	Q2655-60125			PF2282K035NI	Q3938-67949	Q7400-60005	
ADF Input Tray	CE538-60127	CC431-60119		PF2309K106NI	PF2282K042NI	Q3938-67950	CE538-60122	
ADF Assembly	CE538-60121		CC483-60103	PF2309-SVPNI	PF2288-SVPPNR	Q3938-67943	CE865-60121	
Flatbed Scanner	CE861-60110		CC519-67914	IR4068-SVPNI	IR4054-SVPNI	Q3938-60132	CE865-60125	

HP Color MFP Printer Parts

Description	M276	M375	M475	M570	M575	M575C	M775
Control Panel	CF145-60101	CE863-60015	CE863-60015	CZ271-60101	CD644-67916	CD644-67920	CD644-67916
DC Controller	RM1-8704	RM1-8039	RM1-8039	RM1-8119	RM1-8119	RM1-8119	RM1-9371
Delivery Assembly		RM1-8049	RM1-8049				
Deliver Roller							
Drive (Main)	RM1-9328			CD644-67911	CD644-67911	CD644-67911	CE708-67901
(Delivery)							RM1-9377
(Fuser)				RM1-8134	RM1-8134	RM1-8134	CE707-67904
Engine Controller		RM1-8205	RM1-8205				
Formatter Base							
Network and/or Fax Model	CF224-60001	CE855-60001	CE855-60001	CZ272-60001	CD644-67909	CD644-67909	CC522-67933
Wireless	1150-7940	1150-7938	1150-7938	1150-7951	1150-7951	1150-7951	
Fuser	RM1-8780	RM1-8061	RM1-8061	RM1-8054	RM1-8054	RM1-8054	CE514A
Image Drum							
Laser Scanner		RM1-5308	RM1-5308	CD644-67905	CD644-67905	CD644-67905	
LIU/Fax Card	CF206-60001	CE682-60001	CE682-60001	CF206-60001	CC478-67901	CC478-67901	CC522-67929
Main Motor		RM1-5419	RM1-5419	RM1-8105			
Maintenance Kit							
Power Supply High/Upper	RM1-8705	RM1-8031	RM1-8031	RM1-8088	RM1-8088	RM1-8088	RM1-6800
Power Supply High/Lower							
Power Supply Low	RM1-9012	RM1-9034	RM1-9034	RM1-8102	RM1-8102	RM1-8102	RM1-8895
Registration		RM1-4841	RM1-4841	RM1-4969	RM1-4969	RM1-4969	
Service Manual	CF144-90934	CE863-90966	CE863-90966	CZ271-91020	CZ271-91020	CZ271-91020	CC522-90967
Toner (B)	CF210-67901	CE410-67901	CE410-67901	CE400A/X	CE400A/X	CE400A/X	CE340A
(C) (Y) (M) *	211*212*213*	411*412*413*	411*412*413*	1A*2A*3A*	1A*2A*3A*	1A*2A*3A*	41*42*43*
Transfer Kit	RM1-8777	RM1-4852	RM1-4852	CD644-67908	CD644-67908	CD644-67908	CC522-67911
Transfer Roller	RM1-4445	RM1-8043	RM1-8043	CD644-67914	CD644-67914	CD644-67914	CC522-67912
Tray 1 P/U Assembly							
Tray 1 P/U Roller	RM1-8047	RL1-1802	RL1-1802	CD644-67903	CD644-67903	CD644-67903	CC522-67928 Kit
Tray 1 Sep Pad	RM1-8765	RL1-1785	RL1-1785				
Tray 2 P/U Assembly				RM1-4967	RM1-4967	RM1-4967	CE522-67903
Tray 2 P/U Roller		RM1-8047	RM1-8047	RM1-4968	RM1-4968	RM1-4968	CC522-67927 Kit
Tray 2 Sep Pad							
Tray 2 Feed/Sep Roller		RM1-4840	RM1-4840	RM1-4966	RM1-4966	RM1-4966	
Tray 3 P/U Assembly				RM1-5919	RM1-5919	RM1-5919	
Tray 3 P/U Roller		RM1-8047	RM1-8047	RL1-2099	RL1-2099	RL1-2099	CC522-67909 Kit
Tray 3 Sep Pad							
Tray 3 Feed/Sep Roller		RM1-4840	RM1-4840	RM1-0037x2	RM1-0037x2	RM1-0037x2	
High Capacity P/U Roller							5851-5011 Kit
High Capacity Feed/Sep							
ADF Parts							
ADF Maintenance Kit							
ADF P/U Roller		5851-3580	5851-3580		L2725-60002 Kit	L2725-60002 Kit	L2725-60002 Kit
ADF Sep Roller							
ADF Sep Pad		Q2665-60125	Q2665-60125				
ADF Input Tray		CE863-60113					
ADF Assembly	CF144-60128	CE863-60106	CE830-60101	CZ271-60016	CD644-67918	CD644-64921	CC522-67923
Flatbed Scanner	CF144-60130	CE903-60101	CE863-60119	CZ271-60015	CD644-67922	CD646-67901	CC522-67922

HP Firmware Versions and Part Numbers

PRINTER	FIRMWARE VERSION	PART #	UPGRADE TYPE	REQUIRED MEMORY
LJ 2200		C7067-67903		NO
LJ 2300	04.050.2	Q2677-67911	DIMM & RFU	NO
LJ 2300 (Duplex)	04.050.2	Q2677-67910	DIMM & RFU	NO
LJ 2410/20	08.112.3		RFU	32Mb DDR
LJ 2430	08.112.3		RFU	48Mb DDR
LJ 3050/52/55 MFP	20070331 REV G		RFU	
LJ 3200 MFP	20020612	C7867-69007	DIMM & RFU	8Mb PC100
LJ 3300/10/20/30 MFP	20021018W		RFU	NO
LJ 3380	20040802 REV E		RFU	
LJ 3390/92 MFP	20070331 REV G		RFU	
LJ 4050	UPGRADE KIT 6.36	C4251-67905	DIMM	NO
LJ 4100	01.040.2	C4168-67907	DIMM	16Mb or 32Mb PC100
LJ 4100 MFP	03.804.6	C9168-67913	DIMM & RFU	64Mb PC100
LJ 4101 MFP	03.804.6	C9168-67913	DIMM & RFU	64Mb PC100
LJ 4200	04.020.3	Q2453-67908	DIMM & RFU	NO
LJ 4240	08.016.2		RFU	64Mb DDR
LJ 4250	08.016.2		RFU	48Mb DDR
LJ 4300	04.020.3	Q2453-67917	DIMM & RFU	NO
LJ 4345 MFP	09.141.4	Q7725-67992	CFM & RFU	
LJ 4350	08.016.2		RFU	80Mb DDR
LJ 5000	UPGRADE KIT	C4251-67905	DIMM	NO
LJ 5100	MB8.23	Q2449-67908	DIMM & RFU	
LJ 5200	08.061.2	Formatter	RFU	
LJ 8000	4.62	C4085-60009	DIMM	NO
LJ 8100		C4214-60009	DIMM	NO
LJ 8150	MB7.119	C8530-67909	DIMM & RFU	32Mb PC100(Single Side)
LJ 9000	02.516.0	C9147-69005	DIMM & RFU	64Mb PC100
LJ 9000 MFP	03.804.6	C9147-69009	DIMM & RFU	64Mb PC100
LJ 9040/50 MFP	08.131.3	Q7725-67994	CFM & RFU	
LJ 9055/65	07.006.6	C9147-67930	DIMM & RFU	
LJ9040/9050	8.111.1	Q7725-67980	CFM & RFU	
M1005 MFP	20070302		RFU	
M1120 MFP	20080908		RFU	
M1319 MFP	20090724		RFU	
M1522 MFP	20090403		RFU	
M2727 MFP	20090403		RFU	
M3027/M3035	48.091.4		RFU	
M4345 MFP	48.091.4		RFU	
M5025 MFP	48.091.4		RFU	
M5035 MFP	48.091.4		RFU	
M9040/M9050 MFP	51.041.3	CE770-67914	CFM & RFU	
P2035	20081120		RFU	
P2055	20090430		RFU	
CFM COMPACT FLASH MEMORY				
RFU REMOTE FIRMWARE UPGRADE				
DIMM DUAL INLINE MEMORY MODULE				
* Firmware Flash is newer than DIMM or CFM				

PRINTER	FIRMWARE VERSION	PART #	UPGRADE TYPE	REQUIRED MEMORY
P3005	02.042.4		RFU	
P3015	N/A yet			
P4014	04.048.4		RFU	
P4015	04.048.4		RFU	
P4515	04.048.4		RFU	
CLJ 2500		C9168CC	DIMM	64Mb PC100
CLJ 2550	20040930		RFU	
CLJ 2600	20070716		RFU	NO
CLJ 2605	20071108		RFU	
CLJ 2820 MFP	20070524		RFU	
CLJ 2840 MFP	20070524		RFU	
CLJ 3000	46.041.2	CE770-67907	CFM & RFU	
CLJ 3500	01.000.4		RFU	NO
CLJ 3550	02.003.2		RFU	NO
CLJ 3600 DC Controller	1.52		RFU	
CLJ 3600 Formatter	03.003.1		RFU	NO
CLJ 3700	06.008.0 *	Q3992-67906	DIMM & RFU	NO
CLJ 3800	46.040.2	CE770-67906	CFM & RFU	
CLJ 4500	V4.6	C4084-60007	DIMM	NO
CLJ 4550	1.018.0	C9130-67906	DIMM	64Mb 168 pin
CLJ 4600	03.016.0	C9712-69010	DIMM & RFU	64Mb 168 pin
CLJ 4650	07.006.0 *	Q7725-67958	CFM & RFU	128Mb DDR
CLJ 4700	47.034.1	Q7725-67983	CFM & RFU	
CLJ 4730 MFP	46.221.3 *	CE770-67915	CFM & RFU	
CLJ 5500	04.020.3	C9712-69009	DIMM & RFU	64Mb PC100
CLJ 5550	07.013.2	Q7725-67986	CFM & RFU	128Mb DDR
CLJ 9500	05.011.2 *	C9712-67926	DIMM & RFU	
CLJ 9500 MFP	08.131.3	Q7725-67993	CFM & RFU	
CM 2320 MFP	20090209		RFU	
CM1015 MFP	20061120		RFU	
CM1017 MFP	20061120		RFU	
CM1312 MFP	20090209		RFU	
CM3530 MFP	53.021.2		RFU	
CM4730 MFP	50.071.3	CE770-67916	CFM & RFU	
CM6030/6040	52.041.5		RFU	
CM8050/8060	76.008.8		RFU	
CP4005	46.035.3	Q7725-67984	CFM & RFU	
CP6015	04.045.5		RFU	
CP1215	20081007		RFU	
CP1518	20080813		RFU	
CP2025	20081216		RFU	
CP3525	05.058.4		RFU	

HP Jet Direct Cards

For Printers CLJ5, IIISi, 4Si, 5Si, 4, 4+, 5, 4V

Part #	Series	Inputs				Speed	Type		Replaces
		RJ45	BNC	Localtalk	DB9		Ethernet	Token Ring	
J2550A & B		X				10BaseT	X		
J2552A & B		X	X	X		10BaseT	X		
J2555B		X			X			X	
J2556B		X				10/100Base T	X		
J4100A	400n	X	X			10/100Base T	X		J2552B
J4105A	400n	X			X			X	J2552B
J4106A	400n	X				10BaseT	X		J2550B

For Printers: 2100, 2200, 2300, 2500, 4000, 4050, 4100, 4200, 4300, 5000, 5100, 8000, 8100, 8150, 9000, CLJ 4500/4550,

CLJ 4600, CLJ 5500, CLJ 3700, CLJ 9500, CLJ 8500/8550

Part #	Series	Inputs				Speed	Type		Replaces
		RJ45	BNC	Localtalk	DB9		Ethernet	Token Ring	
J3110A	600N	X				10BaseT	X		
J3111A	600N	X	X	X		10BaseT	X		
J3112A	600N	X			X			X	
J3113A	600N	X				10/100BaseT	X		
J4167A	610N	X			X			X	J3112A
J4169A	610N	X				10/100BaseT	X		J3113A
J6057A	615N	X				10/100BaseT	X		J4169A
J7934A	620N	X				10/100BaseT	X		J6057A
J7960G	625N	X				10/100BaseT	X		J7934A

HP LaserJet - Entering Service Mode

HP LaserJet 8000, 8100, and 8150 Series service mode

1. Hold down SELECT and JOB CANCEL while powering on the printer, until all lights are illuminated and the Display is blank.
(If the Display Panel reads INTERNAL TEST at this point, the keys were released too soon. Repeat this step until successful.)
2. Press MENU RIGHT, then SELECT. The message SERVICE MODE is displayed briefly, then the printer automatically begins initialization.
After several seconds, both Control Panel Indicators turn off. (The printer may display WARMING UP if it has not warmed up completely.)
After the printer has warmed up and passed the self test, SERVICE MODE is displayed.
3. Press MENU once to display SERVICE MENU.
4. Once it says SERVICE MENU press ITEM to scroll through service mode items.
To exit the Service Mode press [Go].

HP LaserJet 5Si service mode

1. Hold down [Items] and [+] while powering ON the printer, until all lights are illuminated and the Display is blank.
(If the Display Panel reads INTERNAL TEST at this point, the keys were released too soon. Repeat this step until successful.)
- 2 Press [Select]. The message SERVICE MODE is displayed briefly, then the printer automatically begins an INTERNAL TEST.
After several seconds, both Control Panel Indicators turn OFF. (The printer may display WARMING UP if it has not warmed up completely.)
After the printer has warmed up and passed the self test, SERVICE MODE is displayed.
3. Press [Menus] once to display SERVICE MENU.
4. Once it says SERVICE MENU press ITEM to scroll through service mode items.
To exit the Service Mode press [On Line].

HP LaserJet 4V and 4MV service mode

1. Hold down the [On Line], [Form Feed], and [Enter] keys while powering ON the printer, until all lights are illuminated and the Display Window is blank.
(If the Display Window reads 05 SELF TEST at this point, the keys were released too soon. Repeat this step until successful.)
2. Press the [Form Feed] key, then the [Enter] key. The message SERVICE MODE is displayed briefly, then the printer automatically begins a 05 SELF TEST.
After several seconds, both Control Panel Indicators turn OFF. (The printer may display 02 WARMING UP if it has not warmed up completely.)
After the printer has warmed up and passed the self test, SERVICE MODE is displayed.
4. Once it says SERVICE MENU press ITEM to scroll through service mode items.
To exit the Service Mode press the [On Line] key.

HP LaserJet 5000 series service mode

1. Hold down [Select] and [Cancel Job] while turning on the printer.
(If the control panel reads INITIALIZING, the keys were released too soon.)
2. Press the right side of the [Menu] key, then press [Select]. The message SERVICE MODE is displayed.
3. Press [Menus] once to display SERVICE MENU.
4. Once it says SERVICE MENU press ITEM to scroll through service mode items.
To exit the Service Mode press [Go].

HP LaserJet - Entering Service Mode

HP LaserJet 4100 series service mode

- 1 While turning on the printer, hold down SELECT and CANCEL JOB until all of the lights on the control panel are lit.
2. Press the right side of the MENU key, then press SELECT. The message SERVICE MODE temporarily appears and will reappear when the printer completes the initialization process.
3. Press [Menus] once to display SERVICE MENU.
4. Once it says SERVICE MENU press ITEM to scroll through service mode items.
5. To exit the Service Mode press [Go].

Note: If READY appears in the control panel, the keys might have been released too soon, or the wrong keys were pressed.

HP LaserJet 4000 and 4050 series service mode

1. Hold down [Select] and [Cancel Job] while turning on the printer until all of the lights on the Control Panel are lit.
(If the Control Panel reads INITIALIZING, the keys were released too soon.)
- 2 Press the right side of the [Menu] key, then press [Select]. The message SERVICE MODE is displayed.
3. Press [Menus] once to display SERVICE MENU.
4. Once it says SERVICE MENU press ITEM to scroll through service mode items.
5. To exit the Service Mode press [Go].

HP LaserJet 4 and 4 plus series service mode

1. Hold down the [On Line], [Form Feed], and [Enter] keys while powering ON the printer, until the ON LINE and FORM FEED indicators are both illuminated and the Display Window is blank. (If the Display Window reads 05 SELF TEST at this point, the keys were released too soon. Repeat this step until successful.)
2. Press the [Form Feed] key, then the [Enter] key. The message SERVICE MODE is displayed briefly, then the printer automatically begins a 05 SELF TEST.
After several seconds, the ON LINE and FORM FEED lights turn OFF. (The printer may display 02 WARMING UP if it has not warmed up completely.)
After the printer has warmed up and passed the self test, SERVICE MODE is displayed.
3. Press [Menus] once to display SERVICE MENU.
4. Once it says SERVICE MENU press ITEM to scroll through service mode items.
5. To exit the Service Mode press the [On Line] key.

HP LaserJet 5 series service mode

1. Hold down the Menu+ and Value+ keys while powering on the printer. Hold the keys down until SERVICE MODE is displayed.
2. The interrupted power-on self test is resumed. If the test completes successfully, the message SERVICE MODE is displayed.
3. To exit service mode, press the Go button.

LaserJet's 5P, 6P, 2100, 2200 and other printers that do not have a display panel (LEDs only).

These models are designed as low volume personal printers and do not have maintenance count that needs to be reset or a readily accessible service mode.

You can cold reset these printers or completely reinitialize the NVRAM (nonvolatile random access memory) to factory defaults.

Cold resetting will reset most of the system parameters to factory defaults and reinitializing the NVRAM will reset ALL system parameters to the factory defaults.

Also, there is a service mode for these printers but it is only accessible through software using PJI service mode commands.

Buy the printer's service manual if you want to learn more.

HP LaserJet 5L, 6L, 1100, 1200 do not have a service mode.

You can only perform a cold-reset and continuous self-test.

Lexmark Printer Parts

LEXMARK	S1250	S1255	S1620	S1625	S1650	S1855	S2420	S2450	S2455	Se3455
Engine Code	4059-121	4059-125	4059-162	4059-165	4059-160	4059-185	4059-242	4059-240	4059-245	4059-345
Tray 1 Pickup Assy 250	99A1056	99A1056	99A1056	99A1056	99A1056	99A1056	99A1056			
Tray 1 Pickup Assy 500										
Control Panel	99A0001	99A0001	99A0001	99A0001	99A0001	99A0001	99A0001	99A0001	99A0001	99A0001
Controller Board	99A0187	99A1001	99A0187	99A1002	99A0183	99A1003	99A0183	99A0139	99A1005	99A1006
Engine Board/DC Controller	99A1012	99A1012	99A1016	99A1016	99A1016	99A1018	99A1024	99A1024	99A1024	99A0946
Fuser Assembly	99A1185	99A1185	99A0966	99A0966	99A0966	99A0966	99A1190	99A1190	99A1190	99A1192
High Voltage Power Supply	99A0220	99A0220	99A0220	99A0220	99A0220	99A0220	99A0220	99A0220	99A0220	99A0827
ITC Card Assy/Sensing Board	99A0128	99A0128	99A0128	99A0128	99A0128	99A0128	99A0128	99A0128	99A0128	99A0128
Low Voltage Power Supply	99A2018	99A2018	99A1822	99A1822	99A1822	99A1822	99A2014	99A2014	99A2014	99A2014
Main Drive Assembly	99A0130	99A0130	99A0130	99A0130	99A0130	99A0130	99A0129	99A0129	99A0129	99A0801
Maintenance Kit			99A0967	99A0967	99A0967	99A0967	99A1195	99A1195	99A1195	99A1197
MP Pickup Assembly										
MP Pickup Roller	99A0076	99A0076	99A0076	99A0076	99A0076	99A0076	99A0076			99A0076
MP Separation Pad	99A0083	99A0083	99A0083	99A0083	99A0083	99A0083	99A0083			99A0083
Primary Charge Roller	99A1017	99A1017	99A1017	99A1017	99A1017	99A1017	99A1017	99A1017	99A1017	99A1017
Laser Scanner/Print Head	99A0065	99A0065	99A0065	99A0065	99A0065	99A0398	99A0066	99A0066	99A0066	99A0829
RE Drive 250	99A0091	99A0091	99A0091	99A0091	99A0091	99A0091	99A0091			
RE Drive 500								99A0891	99A0891	99A0891
System Board										
Formatter/DC Controller										
Transfer Roller	99A0179	99A0179	99A0179	99A0179	99A0179	99A0179	99A0179	99A0179	99A0179	99A0179
Tray 1 Pickup Roller	40X0070	40X0070	40X0070	40X0070	40X0070	40X0070	40X0070	40X0070	40X0070	40X0070
Toner	1382920	1382920	1382920	1382920	1382920	1382920	1382920	1382920	1382920	12A0825
Fuser Wiper	99A0725	99A0725	99A0725	99A0725	99A0725	99A0725	99A0725	99A0725	99A0725	99A0725

Lexmark Printer Parts

LEXMARK	T420	T430	T520	T522	T610	T612	T614	T616	T620	T622
Engine Code	4048-001	4048-101	4520-001	4520-210	4069-010	4069-212	4069-414	4069-616	4069-520	4069-722
Engine Code (Network)	4048-002	4048-102	4520-002	4520-220	4069-010	4069-21	4069-41	4069-61	4069-52	4069-72
Tray 1 Pickup Assy 250			99A2157		99A1056					
Tray 1 Pickup Assy 500				99A2079		99A1530	99A1530	99A1530	99A2444	99A2444
Control Panel	56P0602	56P2353	99A2014	99A2014	99A1501	99A1501	99A1501	99A1501	99A1501	99A1501
Controller Board/Formatter			56P1190	56P1192	99A1954	99A1955	99A1956	99A1957		
Controller Board/Formatter{N}			56P1191	56P1193	99A1958	99A1959	99A1960	99A1960		
Engine Board/DC Controller			56P1004	56P1005	56P0584	56P0586	56P0587	56P0588		
Fuser Assembly	56P0648	56P2330	99A2423	99A2423	99A1969	99A1969	99A1977	99A1977	99A2402	99A2405
High Voltage Power Supply	56P0628	56P2322	99A2045	99A2045	99A1823	99A1823	99A1823	99A1823	99A2451	99A2451
ITC Card Assy/Sensing Board			99A0128	99A0128	99A0128	99A0128	99A0128	99A0128	99A0128	99A0128
Low Voltage Power Supply	56P0626	56P2320	99A2043	99A2043	99A1822	99A1822	99A0214	99A0214	99A2452	99A2453
Main Drive Assembly	56P0633	56P2326		99A2030	99A1543	99A1543	99A0129	99A0801	99A2446	99A2447
Maintenance Kit	56P2036	56P2333	99A2420	99A2420	99A1970	99A1970	99A1978	99A1978	99A2408	99A2411
MP Pickup Roller	56P2181	56P2359	99A0076	99A0076	99A0076	99A0076	99A0076	99A0076	99A0076	99A0076
MP Separation Pad	56P6011	56P2311	99A0083	99A0083	99A0083	99A0083	99A0083	99A0083	99A0083	99A0083
Primary Charge Roller	56P0640	56P0640	99A1017	99A1017	99A1017	99A1017	99A1017	99A1017	99A1017	99A1017
Laser Scanner/ Print Head	56P0623	56P2319	99A2026	99A2026	99A1526	99A1527	99A1528	99A1873	99A2448	99A2449
RE Drive 250	56P0608	56P2302	99A2151							
RE Drive 500				99A2029	99A1586	99A1604	99A1533	99A1533	99A1533	99A1533
System Board	56P0617	56P2314							56P1220	56P1222
Formatter/DC Controller {N}	56P0619	56P2315							56P1221	56P1223
Transfer Roller	56P0643	56P0643	99A1015	99A1015	99A1015	99A1015	99A1015	99A1015	99A1015	99A1015
Tray 1 Pickup Roller	56P0618	56P2352	99A0070	99A0070	99A0070	99A0070	99A0070	99A0070	99A0070	99A0070
Toner	12A7410	12A8425-6K	12A6830	12A6830	12A5840	12A5840	12A5840	12A5840	12A6760	12A6760
Toner	12A7415	12A8320	12A6835	12A6835	12A5745	12A5745	12A5745	12A5745	12A6865	12A6865
Fuser Wiper			99A0725	99A0725	99A0725	99A0725	99A0725	99A0725	99A0725	99A0725

Lexmark Printer Parts

LEXMARK	T630	T632	T634	T640	T642	T644	T650	T652	T654
Engine Code	4060-000	4060-200	4060-400	4061-000	4061-200	4061-400	4062-	4062-	4062-
Engine Code (Network)	4060-010	4060-210	4060-410	4061-010	4061-210	4061-410			
Tray 1 Pickup Assy 250	56P1326			40X0067			40X4304		
Tray 1 Pickup Assy 500		56P1325	56P1325		40X0066	40X0066		40X4305	40X4305
Control Panel	56P1310	56P1310	56P1310	40X0010	40X0010	40X0010	40X4462	40X4462	40X4462
Controller Board/Formatter									
Controller Board/Formatter{N}									
Engine Board/DC Controller									
Fuser Assembly	56P2542	56P2542	56P2545	40X2592	40X2592	40X2592	40X4418	40X4418	40X4418
High Voltage Power Supply	56P1375	56P1375	59P1375	40X4275	40X4275	40X4275	40X4362	40X4362	40X4362
ITC Card Assy/Sensing Board	56P1350	56P1350	56P1350	40X0046	40X0046	40X0046			
Low Voltage Power Supply	56P1369	56P1371	56P1371	40x4269	40X4271	40X4271	40X4355	40X4355	40X4355
Main Drive Assembly	56P-1330	56P1332	56P-1858	40X0107	40X0107	40X0107			
Maintenance Kit	56P1409	56P1409	56P1855	40X0100	40X0100	40X0100	40X4724	40X4724	40X4724
MP Pickup Roller	99A0076	99A0076	99A0076	40X0076	40X0076	40X0076			
MP Separation Pad	99A0083	99A0083	99A0083				99A0083	99A0083	99A0083
Primary Charge Roller	99A1017	99A1017	99A1017	40X0127	40X0127	40X0127	40X0127	40X0127	40X0127
Laser Scanner/ Print Head	56P1396	59P1443	56P1854	40X0062	40X0062	40X0062	40X4463	40X4464	40X4464
RE Drive 250	99A2151			40X0029					
RE Drive 500		56P1328	56P1328		40X0030	40X0030			
System Board	56P3080	56P3082	56P3084	40X5923	40X5925	40X5927	40X4375	40X4474	40X5911
Formatter/DC Controller {N}	56P3081	56P3083	56P3085	40X5924	40X5926	40X5928			
Transfer Roller	56P1357	56P1357	56P1357	40X0130	40X0130	40X0130	40X1886	40X1886	40X1886
Tray 1 Pickup Roller	99A0070	99A0070	99A0070	40X0070	40X0070	40X0070	40X4308	40X4308	40X4308
Toner	12A7360	12A7360	12A7360	64015SA	64015SA	64015SA			
Toner									
Fuser Wiper	56P1415	56P1415	56P1415	40X2665	40X2665	40X2665	40X2665	40X2665	40X2665

Lexmark Error Codes

LEXMARK ERRORS	Model	Cause	SOLUTION
991 <device> Card	All T & S	specified device detected an equipment check on system card	check/replace <device>
990 <device>	All T & S	equipment check on device unable to identify failure	check/replace <device>
984 <device>	All T & S	invalid command parameter received by specified device	check/replace <device>
983 <device>	All T & S	invalid command received by the specified device	check/replace <device>
982 <device> Communication	All T & S	communications error detected by specified device	check/replace <device>
981 <device>	All T & S	engine protocol violation detected by specified device	check/replace <device>
980 <device> Communication	All T & S	engine experiencing unreliable communication by device	check/replace <device>
979 Network Card	All T & S	flash parts failed while programming network card	replace network card
978 Network Card	All T & S	bad checksum while programming network card	replace network card
977 Network Card	All T & S	controller detects network card in slot X cannot communicate	replace network card
976 Network Card	All T & S	unrecoverable software error in network card X	replace network card
975 Network Card	All T & S	unrecognizable network card X	replace network card
965 Emulation Error	All ex t62/t63	the download emulation & the controller code are incompatible	(go & menu @power up - perform self test- redownload)
964 Emulation Error	All T & S	download emulation CRC failure. Checksum failure	
963 Ram Error	All ex t63/S	DIMM in slot 3 failed	replace dimm then board
962 Ram Error	All T & S	DIMM in slot 2 failed	replace dimm then board
961 Ram Error	All T & S	DIMM in slot 1 failed	replace dimm then board
960 Ram Memory Error	All T & S	DRAM memory error on controller/system board	replace system/controller
959 System Board	T62/T63	SRAM failure	replace system/controller
958 NAND Error	T62/T63	NAND failure/ SRAM failure	perform power on reset- then replace system/ controller board
957 System Board	T62/T63	ASIC failure	
956 System Board	T62/T63	processor failure	
956 Configuration ID	All ex t62/t63	configuration id from controller is not valid with engine code	set configuration ID
955 Code CRC	T62/T63	ROM & NAND/ ECC failed CRC check	replace system board
954 NVRAM Error	All T & S	NVRAM CRC failure	replace interconnect(t63x) system/engine board
953 NVRAM Error	All T & S	NVRAM chip failure	
951 NVRAM	T63x	secure NVRAM missing	replace system board
950 NVRAM Mismatch	T63x	check for correct system board and correct interconnect board	set configuration ID
949 Delay Line Calibration	All T	indicates a delay in line calibration failure	replace system/engine
948 PEL Clock Error	All T	indicates the PEL clock checked failed	replace system/engine
947 Engine Board	All S/T61	replace engine board	replace engine board
947 PQWT ERROR	T62/T52	PQET ram test was incomplete or ram test busy failure occurred	replace system board
946 Controller Board SRAM	All s/T61/T52	replace controller board	replace controller board

Lexmark Error Codes

LEXMARK ERRORS	Model	Cause	SOLUTION
945 Controller Board ASIC	All s/T61/T52	replace controller board	replace controller board
944 Controller Board Fail	All s/T61/T52	replace controller board	replace controller board
943 Controller Font Version	All s/T61/T52	controller code and FONT ROM are incompatible	replace font chip
941 Controller Code CRC	All s/T61/T52	check for defective simm first then controller board	simm 1st then controller
940 Service LV Supply	All T	low voltage power supply zero crossover test failed	replace low volt
939 Engine/RIP Controller Comm.	All S/T ex t63	the controller/system board can't communicate with engine	control/engine/interconnect
937 Main Drive Motor lost lock	All T & S	see service manual	replace printhead
936 Main Drive Motor initial lock	All T & S	see service manual	replace printhead
935 Mirror Motor	All T & S	mirror motor unable to reach correct speed	replace printhead
934 Mirror Motor	All T & S	lost lock	replace printhead
933 Mirror Motor	All T & S	locks/lost HSYNC	replace printhead
931/932 Printhead lost Hsync	All T & S		replace printhead
930 Printhead Error	All T & S	the wrong printhead was installed	replace printhead
929 Toner Sensor	All T & S	toner sensor/developer drive are not operating/ bad cartridge	see manual
928 Erase Lamps	All S T61	engine has detected either erase lamp is missing or disconnected	see manual
927 Fan Stalled	All T/S ex t52	bad fan if not fan replace system/engine board	fan 1st then board
925 Fuser Error	All T & S	indicates the wrong fuser was installed	install correct fuser
924 Fuser Error	All T & S	an open circuit has been detected in the fuser thermistor circuit	fuser 1st then low volt
923 Fuser Error	All T & S	fuser is to hot during printing or at idle	fuser 1st then low volt
922 Fuser Error	All T & S	fuser has failed to reach standby temperature	fuser 1st then low volt
921 Fuser Error	All T & S	indicates fuser is below standby temperature	fuser 1st then low volt
920 Fuser Error	All T & S	indicates fuser is below temperature while printing	fuser 1st then low volt
917 Transfer Roller	All T & S	check transfer roller arm assembly/bad transfer roller/bad high volt	see cause
914 DC Pick Motor	All T & S	check for correct paper loading /see manual	see manual
913 DC Pick Motor	All T & S	tray 1 paper feed problem has been detected /see manual	see manual
912 DC Pick Motor	All T & S	tray 1 paper feed problem has been detected /see manual	see manual
911 DC Pick Motor	All T & S	tray 1 paper feed problem has been detected /see manual	see manual
910 DC Pick Motor	All T & S	tray 1 paper feed problem has been detected /see manual	see manual
906 Contr/System Board Driver	All T & S	indicates an unrecoverable system/engine software error	replace system/engine
905 Interface Violation Paperport	All T & S	indicates an unrecoverable system/engine software error	replace system/engine
904 Interface Violation software	All T & S	indicates an unrecoverable system/engine software error	replace system/engine
903 Paperport Link Driver	All T & S	indicates an unrecoverable system/engine software error	replace system/engine
902 General Engine Software	All T & S	indicates an unrecoverable system/engine software error	replace system/engine
900/901 RIP Software Error	All T & S	indicates the flash with the system/engine program code is bad	replace system/engine

LPI Contact Information

Departmental Email:

Accounts Payable	AP@LaserPros.com
Accounts Receivable	AR@LaserPros.com
Core Purchasing Specialist	Purchasing@LaserPros.com
Customer Service	Customerservice@LaserPros.com
Human Resources	HR@LaserPros.com
Marketing	Marketing@LaserPros.com
Network/Web Administrator	Administrator@LaserPros.com
Purchasing	Purchasing@LaserPros.com
Returns Merchandise Authorization	RMAOffice@LaserPros.com
Sales	Sales@LaserPros.com
Shipping/Receiving	Shipping@LaserPros.com
Technical Support	Techsupp@LaserPros.com

Fax Numbers:

Sales	715-369-5910
Accounting	715-369-5999
Marketing	715-369-5999
Purchasing	715-369-5999
Technical Support	715-369-5997

Website Key Points

Known for their exceptional Sales and Service staff, www.LaserPros.com has what you need for all of your laser printer solutions~ Register today to gain access to thousands of parts and benefit from these key website features:

- * Access to hundreds of part diagrams, informational articles, tips from our HP certified Technical Support Team, and more!*
- * Easy-to-use "Quick-Order" feature when you know exactly what you want without having to search*
- * Complete library of HP and Lexmark Service Manuals via PDF*
- * Largest supplier for HP, Lexmark, and Canon LaserJet parts*
- * View your Orders, Invoices and RMA history*
- * Real-time inventory to ensure complete order fulfillment*
- * Order 24 hours a day, 7 days a week via 100% Secure Ecommerce Website*